


Item # : LM008-30

Assembly Instructions




If you have any questions, please follow these steps(“Find Your Orders” – “Problem with the Order” – “Contact Seller”) to contact our customer service. Thanks!


Revsied 18/03/2024

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product .




- VI. Power tools should not be used to assemble this product .




- VII. Concealed hinges are three-way adjustable.



Horizontal
by screw adjustment





In-and-Out
by loosening the hinge-arm
mounting screw or via cam
adjustment






















Vertical
Via slots in the mounting
plate or via cam adjustment

Parts List



Hardware List


A		Ø8x30mm	Wooden dowel	24	pcs
B		Ø6x32mm	Cam lock	37	pcs
C		Ø15x9mm	Cam lock	37	pcs
D		Ø30mm	Sticker	37	pcs
F			padlock	1	pc
G		Ø3.5x14mm	Screw	4	pcs
H		Ø4x19mm	Screw	4	pcs
I			Hold hands	2	pcs
J		Ø4x32mm	Screw	20	pcs
K		16"	Drawer slider	2	sets
L		Ø3x12mm	Screw	28	pcs
M			Plastic wedge	8	pcs
N		Ø3x17mm	Screw	8	pcs
O			Anti-inversion hardware	2	pcs
P		Ø3.5*12mm	Screw	2	pcs
Q			Geckos	2	pcs
R		Ø4x40mm	Screw	2	pcs
S			Small White Glue	1	pc



Philips head screwdriver required for assembly
(not included)


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*


Step 1




Put slider bracket into slider arm as per diagram.


Step 2





A

X24

Step 3





B

X37

Step 4




C
X3



Step 5





C
X12


Step 6




L	K
	
X12	X2

Step 7





C

X5

Step 8




Step 9






C
X5

Step10





Step 11




C

X4


Step 12




J

X8

Step 13





J

X2

Step 14




Step 15






J

X10

Step 16





Step 17





I	H
	
X2	X4


Step 18




G	F
X4	X1



Step 19




C

X8

Step 20




K	L
	
X2	X12

Step 21




Step 22






D
O
X8

Step 23




Step 24




L

X4

Step 25





N	M
X8	X8

Step 26







Step 27



S

X2

Step 28



O	P	R
		
X2	X2	X2

Step 29

