


Item # :LM004-18


Assembly Instructions




Revised 21/10/2022

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product .




- VI. Power tools should not be used to assemble this product .




- VII. Concealed hinges are three-way adjustable.



Horizontal
by screw adjustment




In-and-Out
by loosening the hinge-arm
mounting screw or via cam
adjustment






















Vertical
Via slots in the mounting
plate or via cam adjustment

Parts List



Hardware List


| | | | | | |
|---|---|-----------|-------------------|----|-----|
| A |  | Ø8x30mm | Wooden dowel | 8 | pcs |
| B |  | Ø6x35mm | Cam bolt | 8 | pcs |
| C |  | Ø15x11mm | Cam lock | 8 | pcs |
| D |  | Ø30mm | Sticker | 20 | pcs |
| E |  | | Hold hands | 1 | pc |
| F |  | Ø8x5x16mm | Shelf support pin | 8 | pcs |
| G |  | Ø4x19mm | Screw | 1 | pcs |
| H |  | | Electric socket | 1 | pcs |
| I |  | Ø3x12mm | Screw | 2 | pcs |
| J |  | | Door stopper | 1 | pcs |
| K |  | | Bolt | 1 | pcs |
| L |  | Ø4x25mm | Screw | 6 | pcs |
| M |  | Ø4x15mm | Screw | 10 | pcs |
| N |  | | Hinge | 2 | pcs |
| O |  | | Plastic wedge | 4 | pcs |
| P |  | Ø3x17mm | Screw | 4 | pcs |
| Q |  | | Small White Glue | 1 | pc |
| R |  | Ø3x15mm | Screw | 2 | pcs |




Philips head screwdriver required for assembly
(not included)


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1




| |
|---|
| A |
|  |
| X8 |

Step 2





B



X8

Step 3





C



X2

Step 4




C






X2

Step 5





Step6



| R | J |
|---|---|
|  |  |
| X2 | X1 |

Step 7




C




X4


Step8




| |
|-----|
| D |
| O |
| X20 |

Step 9





| |
|---|
| F |
|  |
| X8 |

Step 10






Step 11




| |
|---|
| K |
|  |
| X1 |



Step 12




| G | E |
|---|---|
|  |  |
| X1 | X1 |


Step 13




| M | N |
|---|---|
|  |  |
| X10 | X2 |



Step 14




| |
|---|
| L |
|  |
| X6 |



Step 15




| O | P |
|---|---|
|  |  |
| X4 | X4 |

Step 16



| I | H |
|---|---|
|  |  |
| X2 | X1 |

Step 17



Adjustable feet

Step 18

