


Item # : LM051-326D

Assembly Instructions




If you have any questions, please follow these steps(“Find Your Orders” - “Problem with the Order” - “Contact Seller”) to contact our customer service. Thanks!


Revsied 02/03/2024

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product .




- VII. Power tools should not be used to assemble this product .




- VIII. Concealed hinges are three-way adjustable.



Horizontal
by screw adjustment




In-and-Out
by loosening the hinge-arm
mounting screw or via cam
adjustment




















Vertical
Via slots in the mounting
plate or via cam adjustment

Parts List



Hardware List

A		Ø8x30mm	Wooden dowel	35 pcs
B		Ø6x35mm	Cam lock	48 pcs
C		Ø15x11mm	Cam lock	20 pcs
D		Ø15x9mm	Cam lock	28 pcs
E		Ø30mm	Sticker	48 pcs
F		Ø6x50mm	Bolt	9 pcs
G		M 4	Hex Key	1 pc
H		M6*12mm	Screw	24 pcs
I			Angular Code	12 pcs
J		Ø4x32mm	Screw	28 pcs
K		Ø4x25mm	Screw	3 pcs
L		Ø8x20mm	Wooden dowel	2 pcs
M		Individually packed	Drawer slides	6 Set
N		Ø3x12mm	Screw	72 pcs
O			Plastic wedge	4 pcs
P		Ø3x17mm	Screw	4 pcs




Philips head screwdriver required for assembly
(not included)

*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Hardware List


Q		128mm	Hold hands	2 pcs
R		160mm	Hold hands	4 pcs
S		Ø4x9mm	Screw	12 pcs
T			Anti-inversion hardware	4 pcs
U		Ø4*15mm	Screw	4 pcs
V			House lizard	4 pcs
W		Ø4x35mm	Screw	4 pcs
X			Strip	2 pcs
Y			Small White Glue	1 pc





Philips head screwdriver required for assembly
(not included)


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*


Step 1



L	A
	
X2	X35


Step 2




B

X48

Step 3


M-CL₈




M-CR₈



M-DL₈



M-DR₈






Step 4

NOTE:






Refer to the images to identify M-CL8 (left) and M-CR8 (right). Attach M-CL8 to #3 panel and M-CR8 to #4 panel. [R] screws must go in the exact spots shown.




N	M
X30	X5

Step 5






N	M
	
X6	X1

Step 6






Step 7





C

X4


Step 8




C

X3



Step 9




C

X7



Step 10




G	F
	
X1	X2




Step 11




G	F
	
X1	X7



Step 12




G	I	H
		
X1	X12	X12



Step 13




G	H
	
X1	X2



Step 14




G	H
	
X1	X2


Step 15




G	H
	
X1	X8

Step 16






K

X3

Step 17





Step 18




C

X6

Step 19





J

X8


Step 20



(X2)

Step 21





D

X8



Step 22

NOTE:






Refer to the images to identify M-DL8 (left) and M-DR8 (right). Attach M-DL8 to #15 panel and M-DR8 to #16 panel. [R] screws must go in the exact spots shown.




N	M
	
X12	X2


Step 23




S	Q
	
X4	X2


Step 24




E

X8

Step 25





J

X20

Step 26






Step 27




D

X20

Step 28





N	M
	
X24	X4


Step 29




X4

S	R
	
X8	X4


Step 30




X4


E

X20

Step 31






E

X20

Step 32






Step 33



O	P
	
X4	X4


Step 34



T	U
	
X2	X4


Step 35


Make Four holes 45MM deep




Wall



Step 36




V

X4

Step 37



T	W
	
X2	X4

Step 38



X



X2

Step 39

