


# Item # : LM062-59

## Assembly Instructions




If you have any questions, please follow these steps( “Find Your Orders” - “Problem with the Order” - “Contact Seller” ) to contact our customer service. Thanks!


Revsied 24/06/2024

# General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product .





























- VII. Power tools should not be used to assemble this product .




# Parts List



# Hardware List


A		Ø8x30mm	Wooden dowel	51 pcs
B		Ø6x35mm	Cam bolt	60 pcs
C		Ø15x11mm	Cam lock	52 pcs
D		Ø15x9mm	Cam lock	8 pcs
E		Ø30mm	Sticker	60 pcs
F		M 4	Hex Key	1 pc
G		M6*12mm	Bolt	6 pcs
H			Metal plate	1 pc
I			Handle	2 pcs
J		Ø4x19mm	Bolt	2 pcs
K		Ø4x9mm	Bolt	3 pcs
L			Handle	1 pc
M		12"	Drawer slides	2 Set
N		Ø3x12mm	Screw	36 pcs
O			Three fold hinge	2 pcs
P		Ø6	Iron Hanger	2 pcs
Q			Electric socket	1 pc
R			Door stopper	1 pc
S		Ø3x15mm	Screw	2 pcs
T			Screw	1 pc
U		Ø6x50mm	Screw	5 pcs
V			Plastic wedge	8 pcs
W		Ø3x17mm	Screw	8 pcs
X		Ø4x32mm	Screw	8 pcs
Y		Ø5x13x26mm	Shelf holder	8 pcs
Z			Glue tube	2 pcs




Philips head screwdriver required for assembly  
(not included)


*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*


# Step 1




A

X33

# Step 2





A

X18

# Step 3




# Step 4





B

X24






# Step 5




S	R
	
X2	X1

# Step 6




C

X4



# Step 7



Put slider bracket into slider arm as per diagram.



# Step 8




N	M
	
X6	X1






# Step 10





C

X6

# Step 11





E	B
	
X12	X1

# Step 12




support sth.





C

X1







# Step 13




U	F
	
X3	X1

# Step 14






C

X1

# Step 15







# Step 16




C

X11



# Step 17





C

X4


# Step 18





N	M
	
X6	X1


# Step 19



C

X6


# Step 20





C

X6




# Step 21






E	B
	
X12	X1

# Step 22






# Step 23




C

X1

# Step 24







C

X6

# Step 25






# Step 26




F	G	H
		
X1	X6	X1



# Step 27



U	F
	
X2	X1


# Step 28





N	Q
	
X2	X1







# Step 29




V	W
	
X4	X4

# Step 30




V	W
	
X4	X4


# Step 31




E
O
X27

# Step 32





Y

X8

# Step 33




# Step 34



X

X4


# Step 35











# Step 37




K	L
	
X1	X1

# Step 38





X

X4

# Step 39






# Step 40




P

X2



# Step 41






D

X4

# Step 42




K	I
	
X2	X1



# Step 43



E
O
X8




# Step 44




N	M
	
X12	X2






# Step 45





# Step 46




T	N	O
		
X1	X6	X2



# Step 47



N

X4

# Step 48



J	I
	
X2	X1

# Step 49

