


Item # : LM059-22

Assembly Instructions




If you have any questions, please follow these steps(“Find Your Orders” - “Problem with the Order” - “Contact Seller”) to contact our customer service. Thanks!


Revsied 29/04/2024

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product .

























- VI. Power tools should not be used to assemble this product .




Parts List



Hardware List


A		Ø8x30mm	Wooden dowel	28 pcs
B		Ø6x35mm	Cam bolt	25 pcs
C		Ø15x11mm	Cam lock	25 pcs
E		Ø30mm	Sticker	25 pcs
F		Ø6x50mm	Screw	8 pcs
G		M 4	Hex Key	1 pc
H		M6*12mm	Bolt	6 pcs
I			Plastic wedge	3 pcs
J			Door stopper	1 pc
K		Ø3x15mm	Screw	2 pcs
L			Screw	2 pcs
M		Ø5x13x26mm	Shelf holder	4 pcs
N			Handle	2 pcs
O		Ø4x19mm	Bolt	4 pcs
P		Ø3x12mm	Screw	20 pcs
Q			Three fold hinge	4 Set
R			Anti-inversion hardware	2 pcs
S		Ø4*15mm	Screw	2 pcs
T			House lizard	2 pcs
U		Ø4x35mm	Screw	2 pcs
V			Strip	1 pc
W			Glue tube	1 pc




Philips head screwdriver required for assembly
(not included)


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1






Step 2




B

X22



Step 3





K	J
	
X2	X1


Step 4




G	F
	
X1	X2



Step 5





C

X3

Step 6






G	F
	
X1	X2


Step 7






C
X6

Step 8




C

X2


Step 9




C	G	F
X2	X1	X4




Step 10





B

X3


Step 11





I	G	H
		
X3	X1	X3


Step 12




C

X3



Step 13





C

X3


Step 14





G	H
	
X1	X3

Step 15




C

X6


Step 16




E
O
X25

Step 17







M

X4

Step 18





Step 19




L	P	Q
		
X2	X12	X4



Step 20




P

X8



Step 21



O	N
	
X4	X2


Step 22



R	S
	
X1	X2


Step 23


Make Four holes 45MM deep




Wall



Step 24




T

X2


Step 25



R	U
	
X1	X2

Step 26



V

X1

Step 27

