


Item # : LM063-67

Assembly Instructions




If you have any questions, please follow these steps(“Find Your Orders” – “Problem with the Order” – “Contact Seller”) to contact our customer service. Thanks!


Revsied 07/05/2024

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product .




























- VII. Power tools should not be used to assemble this product .




Parts List



Hardware List


A		Ø8x30mm	Wooden dowel	37 pcs
B		Ø6x35mm	Cam bolt	51 pcs
C		Ø15x11mm	Cam lock	39 pcs
D		Ø15x9mm	Cam lock	12 pcs
E		Ø30mm	Sticker	51 pcs
F		M 4	Hex Key	1 pc
G		M6*12mm	Bolt	8 pcs
H			Corner plate	2 pcs
I			Handle	4 pcs
J		Ø4x19mm	Bolt	2 pcs
K		Ø4x9mm	Bolt	6 pcs
L		Ø4x32mm	Screw	12 pcs
M		12"	Drawer slides	3 Set
N		Ø3x12mm	Screw	38 pcs
O			Electric socket	1 pc
P			Pulley	2 pcs
Q		M6*12mm	Screw	4 pcs
R			Metal plate	2 pcs
S		Ø4*12mm	Screw	4 pcs
T		Ø6	Iron Hanger	2 pcs
U		Ø6x50mm	Screw	8 pcs
V			Plastic wedge	12 pcs
W		Ø3x17mm	Screw	12 pcs
X		Ø5x13x26mm	Shelf holder	8 pcs
Y			Glue tube	2 pcs




Philips head screwdriver required for assembly
(not included)


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*


Step 1




A

X27


Step 2




A

X10


Step 3





B

X23


Step 4




B

X20



Step 5




C

X2



Step 6




U	F
	
X2	X1

Step 7






U	F
	
X4	X1

Step 8





Step 9




C

X8

Step 10




B

X2



Step 11





Put slider bracket into slider arm as per diagram.


Step 12





N	M
	
X18	X3


Step 13




C

X2

Step 14






C

X2

Step 15






Step 16




C

X4

Step 17




E	B
	
X8	X2



Step 18





V	W
X4	X4


Step 19





V	W
	
X8	X8




Step 20





C

X2


Step 21




U	F	C
		
X2	X1	X2




Step 22





C

X2


Step 23




F	G	H
		
X1	X4	X2



Step 24




C

X7



Step 25




F	G
	
X1	X4


Step 26




E	B
	
X23	X4

Step 27






X

X8

Step 28








Step 29




R	S
	
X2	X4

Step 30




J	I	Q	P
			
X2	X1	X4	X2


Step 31





Step 32





Step 33




N	O
	
X2	X1


Step 34




C

X4


Step 35




C

X4

Step 36






L

X8

Step 37




Step 38





D

X4


Step 39


X2




K	I
	
X4	X2

Step 40





L

X4

Step 41






Step 42




T

X2



Step 43




D

X4

Step 44




K	I
	
X2	X1

Step 45




Step 46





E
O
X12

Step 47




N	M
X18	X3

Step 48



Step 49



E
O
X8

Step 50

