


# Item # : LM060-24

## Assembly Instructions




If you have any questions, please follow these steps( “Find Your Orders” – “Problem with the Order” – “Contact Seller” ) to contact our customer service. Thanks!


Revsied 20/05/2024

# General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product .























- VII. Power tools should not be used to assemble this product .




# Parts List



# Hardware List










A		Ø8x30mm	Wooden dowel	16 pcs
B		Ø6x35mm	Cam bolt	21 pcs
C		Ø15x11mm	Cam lock	16 pcs
D		Ø15x9mm	Cam lock	5 pcs
E		Ø30mm	Sticker	21 pcs
F		Ø6x50mm	Screw	4 pcs
G		M 4	Hex Key	1 pc
H		M6*12mm	Bolt	16 pcs
I			Plastic wedge	8 pcs
J			Door stopper	1 pc
K		Ø3x15mm	Screw	2 pcs
L			Screw	2 pcs
M		Ø5x13x26mm	Shelf holder	4 pcs
N		Ø4x32mm	Screw	5 pcs
O			Handle	2 pcs
P			Knob	2 pcs
Q		Ø4x9mm	Bolt	2 pcs
R		Ø4x19mm	Bolt	4 pcs
S		Ø3x12mm	Screw	32 pcs
T			Three fold hinge	4 Set




Philips head screwdriver required for assembly  
(not included)

*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*

# Hardware List


U		Individually packed	Drawer slides	1 Set
V			Plastic wedge	16 pcs
W		Ø3x17mm	Screw	16 pcs
X			Anti-inversion hardware	4 pcs
Y		Ø4*15mm	Screw	4 pcs
Z			House lizard	4 pcs
AA		Ø4x35mm	Screw	4 pcs
BB			Strip	2 pcs
CC			Glue tube	1 pc




Philips head screwdriver required for assembly  
(not included)


*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*


# Step 1




A

X16



# Step 2



B

X21

# Step 3




K	J
	
X2	X1




Step 4


U-CL<sub>8</sub>




U-CR<sub>8</sub>



U-DL<sub>8</sub>



U-DR<sub>8</sub>





# Step 5


NOTE:




Refer to the images to identify U-CL8 (left) and U-CR8(right). Attach U-CL8 to #3 panel and U-CR8 to #4 panel. [S] screws must go in the exact spots shown.



Make sure the rollers on the slides face downward.





U-CR8






U-CL8

Make sure the rollers on the slides face downward.


S	U
	
X6	X1

# Step 6






C

X4

## Step 7




Step 8






C

X4

## Step 9







# Step 10



G	F
	
X1	X4



# Step 11




I	G	H
		
X8	X1	X8






# Step 12




C

X4

# Step 13






G	H
	
X1	X8

## Step 14




# Step 15




C

X4


# Step 16




E
○
X16

# Step 17





M

X4

## Step 18




# Step 19




N

X5




# Step 20




# Step 21



D

X5

## Step 22




E
O
X5

# Step 23

NOTE:






Refer to the images to identify U-DL8 (left) and U-DR8 (right). Attach U-DL8 to #17 panel and U-DR8 to #18 panel. [S] screws must go in the exact spots shown.




U	S
X1	X6

# Step 24







P	Q
	
X2	X2

## Step 25





# Step 26



L	S	T
		
X2	X12	X4


## Step 27





S

X8






# Step 28




R	O
	
X4	X2



## Step 29



V	W
	
X16	X16


## Step 30




X	Y
	
X2	X4


## Step 31

**Make Four holes 45MM deep**




# Step 32






Z

X4

# Step 33




Wall



X	AA
	
X2	X4

## Step 34



BB



X2

## Step 35

