


Item # : LM068-67

Assembly Instructions




If you have any questions, please follow these steps(“Find Your Orders” - “Problem with the Order” - “Contact Seller”) to contact our customer service. Thanks!


Revsied 13/05/2024

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product .
























- VII. Power tools should not be used to assemble this product .




Parts List



Hardware List


A		Ø8x30mm	Wooden dowel	32 pcs
B		Ø6x35mm	Cam bolt	43 pcs
C		Ø15x11mm	Cam lock	35 pcs
D		Ø15x9mm	Cam lock	8 pcs
E		Ø30mm	Sticker	43 pcs
F		M 4	Hex Key	1 pc
G		M6*12mm	Bolt	8 pcs
H			Corner plate	2 pcs
I			Handle	3 pcs
J			M Upper pulley	2 pcs
K			Down pulley	2 pcs
L		Ø4x32mm	Screw	8 pcs
M		12"	Drawer slides	2 Set
N		Ø3x12mm	Screw	48 pcs
O			Electric socket	1 pc
T		Ø6	Iron Hanger	2 pcs
U		Ø6x50mm	Screw	8 pcs
V			Plastic wedge	12 pcs
W		Ø3x17mm	Screw	12 pcs
X		Ø5x13x26mm	Shelf holder	8 pcs
Y			Glue tube	1 pcs




Philips head screwdriver required for assembly
(not included)


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*


Step 1




A

X22


Step 2




A

X10


Step 3




B

X19



Step 4




B

X16

Step 5






U	F
	
X6	X1

Step 6





Step 7




C

X6

Step 8




B

X2



Step 9





Put slider bracket into slider arm as per diagram.


Step 10





N	M
	
X12	X2


Step 11




C

X2

Step 12






C

X2

Step 13






Step 14




C

X4



Step 15




E	B
	
X8	X2



Step 16




V	W
	
X4	X4


Step 17





V	W
	
X8	X8

Step 18





C

X2


Step 19




U	F	C
X2	X1	X2




Step 20





C

X2


Step 21




F	G	H
		
X1	X4	X2



Step 22




C

X7



Step 23




F	G
	
X1	X4


Step 24




E	B
	
X19	X4

Step 25







X

X8

Step 26






Step 27




N	K	J
		
X16	X2	X2

Step 28




I	N
	
X1	X2


Step 29




Step 30





Step 31




C

X4


Step 32




C

X4

Step 33






L

X4

Step 34






Step 35




D

X4


Step 36




N	I
	
X2	X1

Step 37





L

X4

Step 38






Step 39




T

X2



Step 40




D

X4

Step 41




N	I
	
X2	X1

Step 42




Step 43





E
O
X8

Step 44




N	M
X12	X2

Step 45



Step 46



E
O
X8

Step 47

