


Item # : LM052-526D

Assembly Instructions




If you have any questions, please follow these steps(“Find Your Orders” – “Problem with the Order” – “Contact Seller”) to contact our customer service.
Thanks !


Revsied 30/03/2024

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product .




- VII. Power tools should not be used to assemble this product .




- VIII. Concealed hinges are three-way adjustable.



Horizontal
by screw adjustment




In-and-Out
by loosening the hinge-arm
mounting screw or via cam
adjustment




















Vertical
Via slots in the mounting
plate or via cam adjustment

Parts List



Hardware List

A		Ø8x30mm	Wooden dowel	38	pcs
B		Ø6x35mm	Cam lock	48	pcs
C		Ø15x11mm	Cam lock	18	pcs
D		Ø15x9mm	Cam lock	30	pcs
E		Ø30mm	Sticker	48	pcs
F		Ø6x50mm	Bolt	10	pcs
G		M 4	Hex Key	1	pc
H		M6*12mm	Screw	28	pcs
I			Angular Code	14	pcs
J		Ø4x32mm	Screw	30	pcs
K		Ø4x25mm	Screw	5	pcs
L		Ø8x20mm	Wooden dowel	4	pcs
M		Individually packed	Drawer sildes	6	set
N		Ø3x12mm	Screw	72	pcs
O			Plastic wedge	6	pcs
P		Ø3x17mm	Screw	6	pcs




Philips head screwdriver required for assembly
(not included)

*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Hardware List


R		160mm	Hold hands	6	pcs
S		Ø4x9mm	Screw	12	pcs
T			Anti falling hardware	4	pcs
U		Ø4x15mm	Screw	4	pcs
V			House lizard	4	pcs
W		Ø4x35mm	Screw	4	pcs
X			Strip	2	pcs
Y			Small White Glue	2	pcs



Philips head screwdriver required for assembly
(not included)


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*


Step 1



L	A
X4	X38


Step 2





B

X48

Step 3


M-CL8



M-CR8



M-DL8



M-DR8


Step 4




NOTE:

Refer to the images to identify M-CL8 (left) and M-CR8 (right). Attach M-CL8 to #3 panel and M-CR8 to #4 panel. [N] screws must go in the exact spots shown.



M-CL8



M-CR8



Make sure the rollers on the slides face downward.



Make sure the rollers on the slides face downward.

M	N
X6	X18


Step 5




NOTE:

Refer to the images to identify M-CL8 (left) and M-CR8 (right). Attach M-CL8 to #5 panel and M-CR8 to #5 panel. [N] screws must go in the exact spots shown.



M-CL8



M-CR8





Make sure the rollers on the slides face downward.




Make sure the rollers on the slides face downward.



M	N
X6	X18


Step 6






C

X4


Step 7





C

X2


Step 8




C

X2



Step 9




C

X4




Step 10




G	F
	
X1	X10



Step 11




G	I	H
		
X1	X14	X14



Step 12




G	H
	
X1	X2



Step 13




G	H
	
X1	X2

Step 14





G	H
	
X1	X10

Step 15






Step 16




K

X5

Step 17




C

X6


Step 18




E
O
X18

Step 19





J

X30

Step 20





X6

Step 21



D
X15

Step 22




D
X15

Step 23



NOTE:

Refer to the images to identify M-DL8 (left) and M-DR8 (right). Attach M-DL8 to #21 panel and M-DR8 to #22 panel. [N] screws must go in the exact spots shown.




E	N	M
X3	X18	X3

Step 24




NOTE:




Refer to the images to identify M-DL8 (left) and M-DR8 (right). Attach M-DL8 to #21 panel and M-DR8 to #22 panel. [N] screws must go in the exact spots shown.




E	N	M
X3	X18	X3




Step 25




E	R	S
		
X12	X3	X6

Step 26






E	R	S
		
X12	X3	X6

Step 27






Step 28



P	O
	
X6	X6


Step 29




U	T
	
X4	X2


Step 30

Make Four holes 45MM deep






Step 31




V

X4


Step 32



W	T
	
X4	X2

Step 33



X

X2

Step 34

