


Serial Number: SDE05-22

## Shower Door Installation Instructions



**Please do not return the product to the store.  
Contact us with any questions.**

## Model Specific Preparation





### REQUIRED:



Verify threshold and wall with a level.

1/4"(6mm) Maximum out of plumb adjustment from top to bottom


Threshold must be level.



Model width	Shower Door Area
36"	34-5/8"~35-7/16"



PACKAGE CONTENT



PACKAGE CONTENT
















PART#	DESCRIPTION	QTY
A	Wall Jamb	2
B	Stationary Glass-L	1
C	Anti-Water Strip	2
D	Anti-Water Strip	2
E	Glass door-L	1
F	Handle	2
G	Magnetic Strip	2

PART#	DESCRIPTION	QTY
H	Bottom Roller	4
I	Top and bottom Rail	4
J	Rail connector cover	2
K	Top Roller	4
L	Stationary Glass-R	1
M	Glass door-R	1
N	Upright Profile Cover	2
O	Wall Jamb Cover	2



Inspect all parts for missing prior to installation!  
Contact us for any part missing.

## PACKAGE CONTENT




HARDWARE CONTENT




Additional spare parts are included.

aa




Screw anchor  
Ø6x28mm  
7 pcs

bb




Metric Screw  
ST4X30mm  
7 pcs

cc




Screw cap  
10 pcs

dd




Metric Screw  
ST4X16mm  
6 pcs

ee



Washer  
Φ10XΦ5X1.0  
10 pcs

ff




Metric Screw  
ST4X8mm  
4 pcs

NOTE

Inspect all parts for missing prior to installation!  
Contact us for any part missing.


TOOLS REQUIRED

Drill Bits




Ø1/8" & Ø1/4" (3&6mm) dia.  
HSS


Phillips screw driver




Electric hand drill




Level




Silicone gun




Measuring Tape




Soft Head Hammer




Marking Pencil



Utility Knife




Sealant



MASONRY DRILL  
BIT FOR TILE  
Ø6mm




Safety Glasses




Glove




Carpenter's Squarer




Masking or painter's  
tape




Hack Saw



Metal File



Glass suction  
Handle





## SAFETY INFORMATION


### CAUTION

Please carefully read the following important safety information before handling or installing this shower door . There is a risk of serious injury while handling this product.

To minimize these risks, please note:

- Always wear safety glasses and gloves while handling.
- Always follow the installation instructions.
- Inspect glass for damage before installation.
- Extreme caution should be taken while handling the glass during installation as the tempered glass may shatter if in contact with a hard surface.
- Do not cut or modify the tempered glass as it will shatter if cut.
- Carefully remove product from packaging and keep packaging until installation is complete.
- Inspect all parts for damage or missing; if there is damage or part missing to the unit prior to installation, please contact customer service at the number provided in this guide.
- Cover the drain with tape to prevent the loss of small parts.
- The shower base and finished walls should be installed before beginning the shower door installation.
- During the installation, protect the shower floor with a drop cloth to avoid damage.
- This product should be installed by two people who are familiar with construction requirements. Professional installation is recommended!
- Keep this installation manual for future reference.

**NOTE:** Two people should perform this installaton.




## 1


Measure the finished opening width.

NOTE

- 1.Measure the finished opening width at the bottom and at the model height.
- 2.Also check the threshold for level and the walls for plumb.



1/4"(6mm) Maximum out of plumb adjustment from top to bottom



Finished opening difference (X1)&(X) within 1/4"(6mm)

Finished opening difference (Y1)&(Y) within 1/4"(6mm)



## 2

Determine your step in from the edge of tray and plumb your **Wall Jambs(A)**.

Model width	X	Y
36"	34-5/8"~35-7/16"	34-5/8"~35-7/16"

NOTE

1. Mark the wall at the threshold according to the dimensions for the model size shown in Table 1

2. Place the Wall Jamb (A) against the walls and aligned with the new reference marks on the threshold. Use a level to plumb each **Wall Jamb(A)**.






Fig.a



The arc faces outward

Fig.b



**NOTE:** This enclosure must be installed at the model size dimensions shown in Table 1.




Be sure that the correct size shower enclosure has been ordered to fit the finished dimensions of the base or threshold that the enclosure will be installed on.

**NOTE:** The thickness of the finished wall treatment will effect where the enclosure will align upon the threshold.

## 3 Drill screw holes for **Wall Jamb(A)** and insert in the **Wall Anchor(aa)**.

NOTE

1. Drill holes with  $\Phi 6\text{mm}$ (1/4") drill bit as Fig.a.
2. Insert the **Wall Anchors(aa)** as Fig.b.





NOTE

- If a Stud is present behind the wall:  
drill  $\Phi 1/8"$ (3mm) pilot holes into the stud and use the ST4.0x30mm **Screws(bb)**  
OR
- If NO Stud is present behind the wall:  
drill  $\Phi 1/4"$ (6mm) holes and insert the **Wall Anchors(aa)** and use the ST4.0x30mm **Screws(bb)**.

## 4 Install Wall Jambs(A).

**NOTE** 1. Fix **Wall Jambs(A)** with **Screw(bb)** as Fig.a .




## 5

### Install Top and Bottom Rail(I).

NOTE




- 1.Install the **Top and bottom Rail(I)** on the **Stationary Glass-L(B)** and fix it with a screwdriver as Fig.a & Fig.b & Fig.c and Fig.d .
- 2.Secure the glass clamp with a screwdriver as Fig.e .



## 6 Install **Stationary Glass-L(B)**

NOTE

1. Install the **Stationary Glass-L(B)** in the **Wall Jamb(A)** as Fig.a and Fig.b .



**CAUTION:** Do not put glass directly on the ground




## 7

### Install Top and Bottom Rail(I).

NOTE

1. Install the **Top and bottom Rail(I)** on the **Stationary Glass-R(L)** and fix it with a screwdriver as Fig.a & Fig.b & Fig.c and Fig.d .

2. Secure the glass clamp with a screwdriver as Fig.e .








## 8 Install **Stationary Glass-R(L)**.





NOTE

1. Install the **Stationary Glass-R(L)** in the **Wall Jamb(A)** as Fig.a and Fig.b .




## 9

### Install Rail Connector Cover(J).



NOTE


1. Install the **Rail connector cover (J)** on the **Top and Bottom Rail(I)** as Fig.a and Fig.b .
2. Install **Screws(dd)** and screw cover cap **Washers(ff)** as Fig.c .
3. Install **Screw caps(cc)** as Fig.c.








# 10 Install Top Roller(K) and Bottom Roller(H)

NOTE

1.Install the **Roller(H&K)** on the **Glass door-L(E)** as Fig.a & Fig.b & Fig.c & Fig.d & Fig.e and Fig.f .



## 11 Install Glass door-L(E).




NOTE

- 1.Lift the door assembly and fit the **Top Roller(K)** into Top Rail as Fig.a.
2. Press the **Bottom Roller(H)** to fit into the Bottom Rail. And then,release the **Bottom Roller(H)** to hold the door assembly in place as Fig.b & Fig.c and Fig.d .

## 12 Install Top Roller(K) and Bottom Roller(H)

NOTE

1. Install the **Roller(H&K)** on the **Glass door-R(M)** as Fig.a & Fig.b & Fig.c & Fig.d & Fig.e and Fig.f .





## 13 Install Glass door-R(M).




Fig.a




Fig.b




Fig.c





Fig.d



NOTE


- 1.Lift the door assembly and fit the **Top Roller(K)** into Top Rail as Fig.a.
2. Press the **Bottom Roller(H)** to fit into the Bottom Rail. And then,release the **Bottom Roller(H)** to hold the door assembly in place as Fig.b & Fig.c and Fig.d .



## 14 Install the **Magnetic Strip(G)** .

NOTE




- 1.Install the **Magnetic Strip(G)** on the **Glass door-L(E)** as Fig.a and Fig.b .
- 2.Install the **Magnetic Strip(G)** on the **Glass door-R(M)** as Fig.c and Fig.d .



## 15 Install the **Connector(I&O&J)**.

NOTE



1. Use a Allen wrench to adjust the **Top Rollers (K)** left and right so that the **Magnetic Stripe (G)** is engaged as Fig.a .



# 16 Lock Stationary Glass(B&L)

NOTE


1. Drill 6 holes on the inside of the **Wall Jamb(A)** with 1/8"(3mm) drill bit as Fig.a .
2. Install **Screws(dd)** and screw cover cap **Washers(ff)** as Fig.b .
3. Install **Screw caps(cc)** as Fig.c .



## 17 Installing the **Anti-Water Strip(D)** and **Handle (F)**

NOTE


1. Install the **Anti-Water Strip(D)** on the **Glass Door (E&M)** as Fig.a & Fig.b & Fig.c and Fig.d .
- 2.Install **Handle(F)** as Fig.c .



## 18 Install **Anti-Water Strip(C)**

NOTE




1. Install the **Anti-Water Strip(C)** on the **Stationary Glass (B&L)** as Fig.a & Fig.b & Fig.c and Fig.d .



## 19 Install **Upright Profile Cover(N)** and **Wall Jamb Cover(O)**

NOTE

1. Install **Upright Profile Cover(N)** and **Wall Jamb Cover(O)** as Fig.a and Fig.b .





## 20 SEALING



The surfaces need to be clean and free of debris before applying silicone.





Ensure that the Shower door closes tightly and opens smoothly. Apply a good quality silicone sealant along the **Wall Jamb(A)** and **Top and bottom Rail(I)**.



Allow 24 hours for the silicone to cure before using the shower.



The shower room needs to be sealed inside and out



! Apply Silicone Sealant, (not supplied).

## 21

### SEALING

NOTE


The surfaces need to be clean and free of debris before applying silicone.

NOTE

Ensure that the Shower door closes tightly and opens smoothly.  
Apply a good quality silicone sealant along the **Wall Jamb(A)** and **Top and bottom Rail(I)**.



Allow 24 hours for the silicone to cure before using the shower.



24

hour



Apply Silicone Sealant,(not supplied).



The shower room needs to be sealed inside and out