


# **CROSLEY**












---

## FURNITURE













### Pantry Hutch CF3142



# PART LIST


<div>A</div> 	<div>B</div> 	<div>C</div> 	<div>D</div> 	<div>E</div> 
Bottom Panel 1 PC	Left Panel 1 PC	Right Panel 1 PC	Top Panel 1 PC	Left Door 1 PC
<div>F</div> 	<div>G</div> 	<div>H</div> 	<div>I</div> 	<div>J</div> 
Right Door 1 PC	Adjustable Shelf 2 PCS	Back Panel 1 PC	Top Rail 1 PC	Bottom Rail 1 PC
<div>K</div> 				
Cover 2 PCS				

# HARDWARE LIST

<div>#1</div>  <div>Ø8*30mm</div>	<div>#2</div> 	<div>#3</div> 	<div>#4</div> 	<div>#5</div> 
<div>Wood Dowel</div> <div>10 PCS (Extra 1)</div>	<div>Cam Bolt</div> <div>16 PCS (Extra 1)</div>	<div>Cam Lock</div> <div>16 PCS (Extra 1)</div>	<div>Door Hinge</div> <div>4 PCS</div>	<div>Round Head Screw</div> <div>22 PCS (Extra 1)</div>
<div>#6</div>  <div>Ø3.5*12mm</div>	<div>#7</div> 	<div>#8</div>  <div>ØM2</div>	<div>#9</div> 	<div>#10</div> 
<div>Screw</div> <div>28 PCS (Extra 1)</div>	<div>Binding Post</div> <div>2 SETS (Extra 1)</div>	<div>Allen Wrench</div> <div>1 PC</div>	<div>Shelf Holder</div> <div>8 PCS (Extra 1)</div>	<div>Connecting Bar</div> <div>2 PCS</div>
<div>#11</div> 	<div>#12</div> 			
<div>Cover</div> <div>16 PCS</div>	<div>Safety Strap Kit</div> <div>1 SET</div>			

## ADDITIONAL TOOLS (Not Provided)



Note: It is not recommended to use power tools during assembly.





**Phillips Head Screwdriver**



Note: Wood dowels are intended for alignment. Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.


Step 1. Attach door hinges (part #4) to door panels (parts E & F) using screws (part #6) and phillips head screwdriver.




#4  x 4  
#6  x 8



Step 2. Insert cam bolts (part #2) into pre-drilled holes of panels (parts B , C, I & J) using phillips head screwdriver.  
Note : Do not over tighten cam bolts. Stop tightening once threads on cam bolts are no longer visible.



#2  x 16


Step 3. Attach covers (part K) to back panel (part H) using binding posts (part #7) and allen wrench (part #8).





- #7  x 2
- #8  x 1

Step 4. Attach top rail (part I) to bottom panel (part A) and attach bottom rail (part J) to top panel (part D) using wood dowels (part #1), cam locks (part #3) and phillips head screwdriver.


Note : Cam locks must rotate a full 180°. See pictured insert.





- #1  x 2
- #3  x 4

Step 5 . Attach assembled units (parts A, D, I & J) to left panel (part B) using wood dowels (part #1), cam locks (part #3) and phillips head screwdriver.


Note : Cam locks must rotate a full 180°. See pictured insert.




#1  x 4  
#3  x 6


Step 6 . Attach right panel (part C) to assembled unit (parts A, D, I & J) using wood dowels (part #1), cam locks (part #3) and phillips head screwdriver.

Note : Cam locks must rotate a full 180°. See pictured insert.




#1  x 4  
#3  x 6

Step 7. Attach back panel (part H) to assembled unit (parts A, B, C & D) using round head screws (part #5) and phillips head screwdriver.




#5 x 22

Step 8. Carefully turn unit upright. Attach right door (part F) to right panel (part C) using screws (part #6) and phlips head screwdriver.




#6 x 8



Step 9. Attach left door (part E) to left panel (part B) using screws (part #6) and phliips head screwdriver.



#6  x 8


Step 10. Attached covers (part # 11) to the hole of cam locks (part #3). Place shelf holders (part # 9) into desired poission and then slide adjustable shelves (part G) into place.



#9  x 8  
#11  x 16




Step 11. Place pantries together by lining up hutch and base.









Step 12. Attach connecting bars (part #10) to back panels (part H) using screws (part #6) and phillips head screwdriver.

Important: Safety strap kit (part #12) must be installed to prevent tipping, damage and/or injury.

NOTE: It is important to adjust levelers once fully assembled and upright. Extend adjustable leveler until it's firmly in contact with the floor. If relocating, adjust leveler as needed until it's firmly in contact with the floor in new location.




#12	A	B	C	D	E
			 D8*3/4"	 D8*1-1/2"	
Safety Strap Kit 1 SET	Wall Anchor 1 PC	Washer 2 PCS	Short Screw 1 PC	Long Screw 1 PC	Safety Wall Strap 1 PC

## SAFETY WALL STRAP INSTALLATION


Note: It is highly recommended to install this safety strap kit to prevent tipping, damage and/or injury.

1. Insert short screw (C) through washer (B) and safety wall strap (E) and attach to top back panel (part H) using phillips head screwdriver.
2. Drill a 11/32" hole where you want to secure the unit. The drilled hole will be at the same height as the hole in back panel (part H) where the safety wall strap (E) is attached. Tap wall anchor (A) into the hole.
3. Insert long screw (D) through washer (B) and safety wall strap (E) into wall anchor (A) using phillips head screwdriver.

Note: This item is not intended for clothing storage use.




**⚠ WARNING**



**Children have died from furniture tipover. To reduce the risk of furniture tipover:**

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.




*This is a permanent label. Do not remove!*

# ADJUST YOUR DOORS TO MAKE THE GAPS MORE EVEN(OPTIONAL)


## Step 1.

Open the door




## Step 2

Adjust the gap between door panel and side panel




Loosen the screw indicated a little, adjust the hinge to right position (see step 2a & 2b), then tighten the screw.

### Step 2a MOVE DOOR IN



Push the hinge back a little.


### Step 2b MOVE DOOR OUT



Pull the hinge forward a little.


## Step 3

To adjust the gap between two door




Loosen or tighten the screw indicated a little to adjust the gap between doors panels(see step 3a & 3b)

### Step 3a MOVE DOOR RIGHT



Turn the screw clockwise a little as shown to make the gap small.

### Step 3b MOVE DOOR LEFT



Turn the screw counterclockwise a little as shown to make the gap big.