
### **ASSEMBLY INSTRUCTIONS BATH VANITY-CABINET**



Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware. Compare with the parts list to be sure all parts are present. DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED



\* Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe !!! \* Please assemble on a clean soft surface to avoid damage.











(Not included)

(Not included)

**IMPORTANT:** 

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

## PLEASE DO NOT RETURN TO STORE



# Please do not return this product to the retailer!! We are able to assist you in ANY way

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.


## **Before Installation**

#### Important - Please read these instructions fully before starting assembly


Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.


#### **Cam Lock Assembly Instructions**




## **Detail View**





**Identifying the Hardware-**Identify the hardware using the illustrations below.





Hardware Lists - N710P192538		
<b>A</b>	B	C
Ø8*20mm	Ø6*32mm	Ø14.5*9.5mm
Wood dowel (14pcs)	Three in one bolts (6pcs)	Three in one locks (6pcs)
	E ****	
Ø8xØ4*25mm		Ø13xØ1/4*30mm
Round head screw (8pcs)	Damping hinge (2sets)	Hex-Head bolt (4pcs)
G	H	<u> </u>
K4mm		Ø6xØ3*12mm
Allen key (1pc)	Shelf Pin (4pcs)	Round head screw (4pcs)
	Ø5/32*19mm	Ø10x10mm
Handle(2pcs)	Handle screw (4pcs)	Plastic Canopy (8pcs)
	N Ammunia Am	5
Ø8xØ4*50mm  Round head screw (8pcs)	Anti fall Hardware (2sets)	Support Piece (4pcs)
Teg (4pcs)	, and real real water (2000)	- Cappoint 1000 (1400)




















## STEP: 13

Install the sink on the cabinet with glue. Let stand for 24 hours





#### HINGE ADJUSTMENTS




## (1) Sideways / Tilt adjustment

Turn the screw

clockwise to move the door further away from
the side of the cabinet


anticlockwise to move the door closer to the
side of the cabinet



## 2 4 Height adjustment

While supporting the weight of the door, turn the screws

clockwise to move the door up
anticlockwise to move the door down



## (3) Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw

**clockwise** to decrease the gap between the door and the cabinet

anticlockwise to increase the gap between the door and the cabinet

