
# **ASSEMBLY INSTRUCTIONS**



**Bathroom Vanity** 


1	x1	6	x1
2	x1	7	x1
3	x1	8	x1
4	x1		
5	x1		

A	Ø6x26mm	x22		x2
B	Ø15x9mm	x22	J	x2
©	Ø3.5x14mm	×58	K	x8
(D)		x4		
E		x2		
F		x2		
G		x2		
$\Theta$		х4		


## Use the Cam Lock and Eccentric Wheel

#### **ECCENTRIC WHEEL**


Tighten the bolt until the shoulder is aligned with the panel. Be sure not to tighten too much or too little.









The pre-inserted nut should align with the center of the cam lock when joining two panels. The cam lock should be inserted before the eccentric wheel.






Turn the cam lock clockwise to tighten.



WARNING: To prevent tipping over, this product must beused with the included wall mounting device. WARNING: Evaluate the suitability of the wall to ensure thatthe fixtures can withstand the forces that occur.



1pc

1pc


1pc


1pc


A 22pcs

**B**4pcs











## HINGE ADJUSTMENT AND REMOVAL INSTRUCTION






### PIVOT-PRO side adjustment

Side adjustment of the door is made by using the indicated screw.



### **PIVOT-PRO Depth Adjustment**

Depth adjustment is made without loosening any screw. The door can be moved in or outby rotating the cam adjuster on the hinge arm.



### **PIVOT-PRO Height Adjustment**

By loosening the two fixing screws to allow the mounting plate to slide up or down ,the door can be adjusted vertically by  $\pm 2$ mm. After retightening the screws, the Depth adjustment is done.

