


Resin Garden Shed

OWNER'S MANUAL Instructions for Assembly



SLD-B48-V4

Requires three people and take 3-4 hours for installation.
Quick & Easy assembly. Ridge Reinforced Walls.
Available in Various Sizes.

BEFORE YOU START

Owner's Manual

Prior to installation, it is important that you contact your local government authority to determine if building approval is required. Study and understand this owner's manual. Important information and helpful tips will make your construction easier and more enjoyable.

Assembly instructions

Instructions are supplied in this manual and contain all appropriate information for your building model. Review all instructions before you begin. During assembly, follow the step sequence carefully for correct results. Please be aware: this unit takes three people about 3-4 hours to complete.


Parts

Check to be sure that you have all the necessary parts for the building.

Separate contents of the carton by the part number while reviewing parts list.


Familiarize yourself with the hardware and fasteners for easier use during construction. These are packaged within the carton. Note that extra fasteners have been supplied for your convenience.

TOOLS MAY REQUIRED



Use heavy duty gloves when handling steel sheets and flashing

PLAN AHEAD



Watch the weather:

Please be sure the day you select for installation is dry and calm.

DO NOT attempt to assemble your shed in windy weather

because of risk of damage to panels, or personal injury. Be careful of wet or muddy ground.

Teamwork:

Whenever possible, two or more people should work together to assemble the building. One person can position parts or panels

PLAN AHEAD

Site Selection

Avoid overhanging trees as much as possible as leaves will make regular cleaning necessary and broken branches are a potential hazard.

Small trees, bushes or fences nearby can be helpful, acting as a wind break.

If a concrete pad is made, it is important that this slopes towards the edges to prevent water ingress.

Time must be allowed for any concrete or cement to dry before building the shed on top.

Site Preparation

The site must be prepared so that the base of the shed is level all round and checking with a spirit level is required.

The base can be constructed by treated timber or concrete, in order to stop the moisture getting into the shed. The shed is not designed to be built onto lawn directly. Also the ground will get muddy during rainy days.

Bases can also be constructed from bricks, blocks, or mounted on a concrete pad.

The bricks or blocks should be cemented onto firm and level concrete footings and the greenhouse frame drilled and screwed to the base.

IMPORTANT NOTES:

Find someone to help you: it is much easier with someone to hold parts, pass tools etc. Also some steps require two people to lift structures together. This is not very heavy work so would suit most able-bodied people.

































Allow plenty of time: rushing often causes errors and the re-doing of incorrect assemblies. If you have never built a shed before, it can take most of a day to carefully complete the construction.



























Have the right tools to hand.






Safety clothing as recommended in the 'Tools' section.




Ideally lay out the parts and check that all are present before commencing construction. Lay on cloths or plastic sheets if there is any risk of scratching the parts.

Tighten all nuts carefully, being sure not to miss any. Check the frame is square and using a spirit level to check that it is upright.

B48-C01 	x 1	B68-C03 	x 2	A86-C15 	x 4	B48-C11 	x 2
B48-C02 	x 9	B68-C04 	x 4	B48-C06 	x 4	B68-C12 	x 1
B48-C03 	x 1	B48-C04 	x 2	A86-C17 	x 4	A64-C29 	x 2
A64-C04 	x 8	B68-C06 	x 2	B48-C07 	x 4	A64-C30 	x 1
A64-C05 	x 2	B68-C07 	x 6	B68-C08 	x 4	A64-C31 	x 2
B68-C01L 	x 1	A86-C12 	x 2	B48-V4-C03 	x 2	A64-C32 	x 2
B68-C01R 	x 1	B48-V4-C01 	x 8	B48-C09 	x 2	A64-C33 	x 2
B68-C02 	x 2	B48-V4-C02 	x 4	B48-C10 	x 2	A64-C34 	x 1

F35-C27		x 4	A86-V4-A01		x 1	B48-V4-A01		x 8	F35-D02		x 1
F35-C29		x 8	A86-V4-A02		x 1	B48-V4-A02		x 2	A86-D01		x 2
F35-C30		x 4	A64-A02		x 2	A86-V4-A06		x 1			
F35-C31		x 2	B68-A03		x 1	B68-V4-A02		x 1			
F35-C32		x 2	A86-A03		x 1	B48-V4-A03		x 2			
F35-C33		x 2	A64-A05		x 1	A64-V4-A06		x 1			
F35-D03		x 1	A64-A06		x 4	B68-V4-A03		x 1			
F35-C34		x 1	A86-V4-A03		x 1	A64-A15		x 4			








B48-C01 x1



B48-C02 x3



B48-C03 x1




(ST4.2x12)
E02x8

Basement Pre-assembly




A

Place the panel smooth side up, knock the panel tightly by using hammer to make sure the panel is tightly fitted. This will prevent leaks, and then secure it with screws.

It is recommended to have three people install this at the same time, this will help with a better installation.



II



Note : All panels have a rough side and a smooth side. When installing, make sure that the smooth side is toward the inside of the storage shed.


There are card slots on all panels. Align the panel and push it directly with force when installing panels; if it can't be pushed, you can stand the panel up and use the sliding type installation



B48-C02 x6




B48-C04 x2



A64-C32 x2






A64-C33 x2



(ST4.2x12)
E02x20

Side wall Pre-assembly

B




Please repeat this installation process two times.



B68-C07 x6



B68-C06 x2




(ST4.2x12)
E02x12

Back wall Pre-assembly

C




I



x2

Please repeat this
installation process twice.

II



B68-C04 x4


B68-C03 x2

B68-C02 x2

(ST4.2x12)
E02x8



Front wall Pre-assembly

D



x2 Please repeat this installation process twice.

II




A86-C12 x2

B48-V4-C01 x8

B48-V4-C02 x4


B48-V4-A01 x 8


E02 x 44





Roof Pre-assembly


E





Door Pre-assembly F-2






B48-V4-A03x2



A64-V4-A06x1



A86-V4-A06x1







(M6x50)
E08x4




(M6x8.5)
E09x4

Back wall Pre-assembly

G





A




B48-V4-C03 x2




B48-C10 x2




A64-C30 x1




Please use rubber-knife to helping assembly.



a1




a2







B48-C09 x2






F35-C27 x4




(ST4.2x12)
E02x20




Please use rubber-knife to helping assembly.






C x1





B x1




B68-C08 x1




Door



Please use rubber-knife to helping assembly.








D x1




B68-C08 x1




Please use rubber-knife to helping assembly.





C x1





B x1




(ST4.2x12)
E02x8



Door






D x1



B68-C08 x1



Door

B68-C08

D


Please use rubber-knife to helping assembly.



B68-C08 x1





(ST4.2x12)
E02x8




Door

Please use rubber-knife to helping assembly.





E02




B68-V4-A02x1





B68-C12 x1






(ST4.2x12)
E02x28







A86-V4-A01 x1







A86-V4-A02 x1




B68-A03 x1



A86-V4-A03 x 1










B68-C01L x1




B68-C01R x1



(ST4.2x12)
E02x4







F35-C31 x2



F35-C33 x2






F35-C32 x2




(ST4.2x12)
E02x36






Please remove the protective film from the window.
The UV-protected side of the sheet is covered with
white film and must face towards the sun.





(ST4.2x12)
E02x22














A86-C15 x4




B48-C06 x4










B48-V4-A02x2




Gx1



(ST4.2x12)
E02x32





A64-C34 x 1



A64-V4-A06 x 1




E07 x 4




(M6x50)
E08x2



(M6x8,5)
E09x2











A86-C17 x4




B48-C07 x4






(ST4.2x12)
E02x20




a




b







F35-C30 x4







A64-C31 x2




A64-C29 x2





(ST4.2x12)
E02x32






(ST4.2x12)
E02x12











B68-V4-A03 x 1




(ST4.2x12)
E02x18







F-1



F-2





(M4x10)
E12x12






ATTENTION!!


When the door is not vertical or parallel after installation, please make appropriate adjustments according to the following figure.








(ST4.8x19)
E03x28







E04x5

Internal View





F35-D02 x1



(ST4.2x13)
E01x4

