



Item # :LM089-223D Assembly Instructions



If you have any questions, please follow these steps ("Find Your Orders" - "Problem with the Order" - "Contact Seller") to contact our customer service. Thanks!

General Assembly Guidelines

- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.



In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.




M. A Phillips head screwdriver is required for the assembly of this product.



MI. Power tools should not be used to assemble this product .






Hardware List


Α		Ø8x30mm	Wooden dowel	18	pcs
В		Ø6x32mm	Cam bolt	23	pcs
С		Ø15x11mm	Cam lock	4	pcs
D		Ø15x9mm	Cam lock	19	pcs
Ε		Ø30mm	Sticker	23	pcs
F		Ø6x50mm	Screw	4	pcs
G		M4	Hex Key	1	рс
Н		M6*12mm	Bolt	16	pcs
ı			Plastic wedge	8	pcs
J			Plastic wedge	8	pcs
K		Ø3x17mm	Screw	8	pcs
L	<	Ø3x12mm	Screw	32	pcs
М		10"	Drawer slides	3	sets
N			Bounce	3	sets
0		Ø4x32mm	Screw	15	pcs
Р			Glue tube	1	рс
Q			Electric socket	1	рс


Philips head screwdriver required for assembly (not included)


The hardware quantities listed above are required for proper assembly.


Some extra hardware may also have been included.













NOTE:





Refer to the images to identify M-CL (left) and M-CR (right). Attach M-CL to #3 panel and M-CR to #4 panel. [L] screws must go in the exact spots shown.








L	М	
X6	X1	





























NOTE:



Refer to the images to identify M-DL (left) and M-DR (right). Attach M-DL to #14 panel and M-DR to #15 panel. [L] screws must go in the exact spots shown.

