




## Item # : LM091-526D

### Assembly Instructions




If you have any questions, please follow these steps( “Find Your Orders” – “Problem with the Order” – “Contact Seller” ) to contact our customer service. Thanks!


Revised 21/04/2025

## General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product .




- VI. Power tools should not be used to assemble this product .







# Parts List




x1




x1




x1



x1

























x1



x1

## Hardware List






A		Ø8x30mm	Wooden dowel	32	pcs
B		Ø6x32mm	Cam bolt	44	pcs
C		Ø15x11mm	Cam lock	6	pcs
D		Ø15x9mm	Cam lock	38	pcs
E		Ø30mm	Sticker	44	pcs
F		Ø6x50mm	Bolt	6	pcs
G		M4	Hex Key	1	pc
H		M6*12mm	Bolt	24	pcs
I			Plastic wedge	12	pcs
J			Plastic wedge	24	pcs
K		Ø3x17mm	Screw	24	pcs
L		Ø3x12mm	Screw	60	pcs
M			Drawer slides	6	sets
N			Bounce	6	sets
O		Ø4x32mm	Screw	30	pcs
P			Anti-inversion piece	4	pcs
Q		Ø4x15mm	Screw	4	pcs
R			Strip	2	pcs
S			House lizard	4	pcs
T		Ø4x38mm	Screw	4	pcs
U			Glue	2	pcs




**Philips head screwdriver required for assembly  
(not included)**


*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*

# Step 1




A

X32

## Step 2




N
X6


## Step 3



N
X6


# Step 4




B

X44



## Step 5



## Step 6




# Step 7

M-CL




M-CR



## NOTE:






Refer to the images to identify M-CL (left) and M-CR (right). Attach M-CL to #3 panel and M-CR to #4 panel. [L] screws must go in the exact spots shown.





L	M
X18	X6



## Step 8





L	M
	
X24	X4



# Step 9





E	D
	
X2	X2



# Step 10





E	D
	
X2	X2



# Step 11




E	D
	
X2	X2



# Step 12



E	D
	
X2	X2


# Step 13





G	F
	
X1	X6



## Step 14







# Step 15




E	C
X6	X6



# Step 16




G	H	I
		
X1	X12	X12



# Step 17




G	H
	
X1	X2

## Step 18



G	H
	
X1	X2

## Step 19





M






X8

# Step 20



O

X30


# Step 21





E	D
X10	X10



## Step 22




# Step 23







E	D
X10	X10

# Step 24









## Step 25



# Step 26


# Step8




J	K	P	Q
			
X24	X24	X2	X4


## Step 27

Make Four holes 45MM deep




## Step 28




<b>S</b>

<b>X4</b>

## Step 29



## Step 30



R
X2

## Step 31

