


LM093



Scan for Help!
Assembly Guide/Customer Support

Item # : LM093-527D Assembly Instructions




If you have any questions, please follow these steps(“Find Your Orders” - “Problem with the Order” - “Contact Seller”) to contact our customer service. Thanks!


Revised 21/04/2025

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product .




- VI. Power tools should not be used to assemble this product .




Parts List




Parts List




x1




x1




x1




x1



x1
























x1



x1

Hardware List


A		Ø8x30mm	Wooden dowel	26	pcs
B		Ø6x32mm	Cam bolt	54	pcs
C		Ø15x11mm	Cam lock	10	pcs
D		Ø15x9mm	Cam lock	44	pcs
E		Ø30mm	Sticker	54	pcs
F		Ø6x50mm	Bolt	10	pcs
G		M4	Hex Key	1	pc
H		M6*12mm	Bolt	24	pcs
I			Plastic wedge	12	pcs
J			Plastic wedge	22	pcs
K		Ø3x17mm	Screw	22	pcs
L		Ø3x12mm	Screw	84	pcs
M		10"	Drawer slides	7	sets
N			Glue tube	2	pcs
O		Ø4x32mm	Screw	32	pcs
P			Anti-inversion piece	4	pcs
Q		Ø4x15mm	Screw	4	pcs
R			Strip	2	pcs
S			House lizard	4	pcs
T		Ø4x38mm	Screw	4	pcs




**Philips head screwdriver required for assembly
(not included)**








*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1



B

X54

Step 2









A
X26

Step 3






Left hand on the left end of the guide, press the right end with the right thumb.




Step 4

M1






L	M1
	
X18	X6

Step 5




Step 6




L	M1
	
X12	X4



Step 7




Step 8





X2



L	M1
	
X12	X4

Step 9





L	M1
	
X42	X14



Step 10





Assisting balance beam



E	D
	
X2	X2

Step 11




E	D
	
X1	X1



Step 12




E	D
X6	X6



Step 13




E	D
	
X5	X5

Step 14






G	F
	
X1	X4

Step 15




Step 16






E	C
	
X8	X8

Step 17







Step 18




G	F
	
X1	X6



Step 19




G	H	I
		
X1	X12	X12



Step 20




G	H
	
X1	X2



Step 21




G	H
	
X1	X2


Step 22







G	H
	
X1	X8

Step 23



O

X12

Step 24





E	D
X12	X12


Step 25


Attention :

Before assembly, please make sure to adjust the metal piece/ball bearing to the front of the drawer glide for both left and right side slider.






Step 26




O

X20

Step 27



E	D
X20	X20



Step 28




Step 29





Attention :

Before assembly, please make sure to adjust the metal piece/ball bearing to the front of the drawer glide for both left and right side slider.




Step 30




J	K	P	Q
			
X22	X22	X2	X4


Step 31

Make Four holes 45MM deep




Step 32




S

X4

Step 33



Step 34



Step35

