




Amira Glass Bookcase

SKU# WEAMI41OS3



For Residential Use Only


Please visit our website for the most current instructions, assembly tips, report damage, or request parts. www.walkeredison.com



Time to get started


Set up a clean and soft workplace to get started and avoid damage during the assembly. It also helps to double-check that you've got all the pieces and parts before diving in to assembly.

Estimated time for assembly



People recommended for assembly


Make it a team effort! Grab a friend for quicker, easier assembly.



2 People Build


Tools Needed

Grab a Phillips head screwdriver to conquer this assembly




Use power tools with caution

You can cause cracking or damage to the material and easily strip the hardware. If you choose to use a power tool, your product will no longer be covered under Walker Edison's warranty.



Glue is provided to secure wood dowels in place


When inserting dowels, locate the appropriate hole, place a small amount of glue in the hole, and then insert the dowel. Wipe away excess glue immediately.



Scan to get assembly tips and help!














WE Parts List

Part Number	Description	Quantity
1	Top Panel	1
2	Left Side Panel	1
3	Right Side Panel	1
4	Left Side Molding	1
5	Right Side Molding	1
6	Front Molding	1
7	Back panel	1
8	Adjustable Shelf	2
9	Fixed Divider	1
10	Lower Back Panel	1
11	Inner Side Panel	4
12	Fixed Divider Crossbar	1
13	Drawer Middle Crossbar	1
14	Bottom Crossbar	1
15	Left Door Panel	1
16	Right Door Panel	1
17	Drawer Front Panel	2
18	Drawer Left Side Panel	2
19	Drawer Right Side Panel	2
20	Drawer Back Panel	2
21	Drawer Bottom Panel	2
22	Base Cross Bar	2
23	Door Stopper	1














Hardware List

Part	Size	Name	Quantity
A	 8x30mm	Wooden dowel	27
B	 6x35mm	Cam bolt	53
C	 15x11mm	Cam lock	53
D	 30mm	Sticker	53
E	 37x13x6.5mm	Door stopper	1
F	 3x16mm	Screw	2
G		Glue tube	1
H	 20x20x1mm	L Shape Bracket	2
J	 4x12mm	Screw	12
K	 50x50x2mm	Connecting iron sheet	2
L		Plastic wedge	10
M	 3x17mm	Screw	10
N	 8x5x16mm	Shelf support pin	8





Hardware List

Part	Size	Name	Quantity	
Q		35mm	Hinge	6
R		4x16mm	Screw	24
S		6x30mm	Wooden dowel	8
T		31x21x1.5mm	Magnetic iron sheet	2
U		3x12mm	Screw	2
V		75x32x15x1.5mm	Bracket	2
W		5x12mm	Screw	2
X		5x38mm	Screw	4
Y		6x30mm	Wall Anchor	2




*The hardware quantities listed above are required for proper assembly.
Extra hardware pieces may be included.*

Step 1

Let's get started! Using a Phillips head screwdriver, screw cam bolts (B) into the Left Side Panel (2) and the Right Side Panel (3). Then, insert wooden dowels (A) into both pieces.



Tip




1: The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.

2: In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.


Step 2

Screw cam bolts (B) into the Left Side Molding (4) and the Right Side Molding (5).





Step 3

Screw the connecting iron sheet (K) into the Front Molding (6) using the (J) screws. Then, screw cam bolts (B) into the Front Molding (6) and the Top Panel (1) and insert wooden dowels (A) into the Top Panel (1).



Step 4


Connect the Front Molding (6) and the Top Panel (1). Insert cam locks (C) and tighten with a screwdriver. Then, attach the Door Stopper (23) to the Front Molding (6) using the (X) screws and wooden dowels (A).




Tip

Cam Locks


Cam Locks help securely join two pieces together.
Follow these easy steps.



1: Insert Cam Bolt into bolt holes on the flat side. Don't over tighten!




2: Fit the proper holes on the edge of the other part over the Cam Bolts. You should be able to see the cam bolts through the larger hole on the side.



3: On the back of the Cam Lock will be a "C" shape. Insert the Cam Lock so the opening of the "C" fits over the Cam Bolt. Tighten with the screwdriver.


Step 5

Screw cam bolts (B) into the Lower Back Panel (10) and the Fixed Divider (9). Then, insert wooden dowels (A) into the Lower Back Panel (10), Bottom Crossbar (14), Fixed Divider Crossbar (12), and the Fixed Divider (9).




Step 6

Connect the Fixed Divider Crossbar (12) to the Fixed Divider (9). Insert cam locks (C) and tighten with a screwdriver.




Step 7

Connect the Lower Back Panel (10) to the Fixed Divider (9).
Insert cam locks (C) and tighten with a screwdriver.




Step 8

Attach the door stopper (E) to the Fixed Divider (9) using the (F) screws.




Step 9

Secure the Fixed Divider Crossbar (12), Fixed Divider (9), Lower Back Panel (10), Bottom Crossbar (14), and the Drawer Middle Crossbar (13) to the Left Side Panel (2). Insert cam locks (C) and tighten with a screwdriver.




Step 10

Now, secure the Right Side Panel (3). Insert cam locks (C) and tighten with a screwdriver.




Step 11

Insert the Inner Side Panels (11) and secure with a cam lock (C).




Step 12

Next, attach the Left Side Molding (4) and the Right Side Molding (5) to the Left Side Panel (2), Right Side Panel (3), and the Inner Side Panels (11). Insert cam locks (C) and tighten with a screwdriver.




Step 13

Towards the bottom of the unit, attach the L-Shaped Bracket (H) to the Right Side Molding (5) and the Right Side Panel (3) using the (J) screws. Repeat this step for the other side.




Step 14

Unfold the Back Panel (7) and slide it into place using the grooves in the Fixed Divider (9), Right Side Panel (3), and Left Side Panel (2) as your guide.




Step 15

Now, attach the Top Panel (1) to the rest of the unit. Insert cam locks (C) and tighten with a screwdriver.




Step 16

Using the (J) screws, attach a (K) to the inside corners of both the Left Side Molding (4) and the Front Molding (6) as well as the Right Side Molding (5) and the Front Molding (6). This should be inside of the unit and should not be visible from the outside.







Step 17

Attach both brackets (V) to the Top Panel (1) using the (W) screws.




Step 18

Evenly space the plastic wedges (L) in between the Back Panel (7) and the rest of the unit. Secure with (M) screws.




Step 19

Use the provided stickers (D) to ensure a clean finish.




Step 20

Insert shelf support pins (N), then slide in both Adjustable Shelves (8).




Step 21

Attach the hinges (Q) to the Left Door Panel (15) and Right Door Panel (16) using the (R) screws. Then, attach the magnetic iron sheet (T) to the bottom inside corner of both doors using the (U) screw.




Step 22

Secure the hinges (Q) on the Left Door Panel (15) to the Left Side Molding (4) using the (R) screws.




Tip


Adjusting The Cabinet Doors



Adjust horizontal width
with this screw.




Adjust depth position
by loosening the hinge arm
mounting screw.



Adjust vertical height
via the screws in the
mounting plate.


Step 23

Secure the hinges (Q) on the Right Door Panel (16) to the Right Side Molding (5) using the (R) screws.



Step 24



Insert wooden dowels (S) into the Drawer Left Side Panel (18), Drawer Right Side Panel (19), and the Drawer Back Panel (20). Repeat this step once more for the second drawer.



x 2


Step 25

Using the quick assembly mechanism, secure the Drawer Right Side Panel (19) and the Drawer Left Side Panel (18) to the Drawer Back Panel (20).




x 2

Quick Assembly Drawers




1. Make sure the quick assembly drawer pin is aligned with the corresponding hole.



2. Once the pin is inserted correctly, flip the metal lever in the opposite direction to ensure the panels are firmly locked together.


Step 26

For both drawers, attach the Base Cross Bar (22) to the Drawer Back Panel (20) and secure with the quick assembly mechanism.



Step 27


Insert the Drawer Bottom Panel (21) using the grooves as your guide.



x 2



Step 28

Attach the Drawer Front Panel (17) to the drawer and secure with the quick assembly mechanism. Repeat this for the second drawer.




Step 29

Firmly push the drawers all the way into place making sure the drawer member lines up with the inside guides of the cabinet member. Some resistance is normal.




Reinserting your Cabinet Glides together

Line up the Drawer Member so it is inside the guides of the Cabinet Member. Once the connection is made, push the drawer into place entirely. It may not be a smooth glide on your first try, but will improve after it's fully inserted.



Step 30

Secure your unit to the wall using the (X) screw, the Bracket (V), and the (Y) wall anchor.





Warning


Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall. Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.

Step 31

Adjust the feet on the bottom of your unit to ensure it sits level.



Final Assembly



Congratulations on your new piece of furniture!

We would love to hear about it and see it.
Please leave us a review or post a picture with
[#mywalkerredisonhome](#)

Assembling furniture can be tricky sometimes.

Our customer service team, located in Utah, is here for product information, help assembling a product, or for any other customer support issue

Call us at **801-433-3008**

Email us at service@walkeredison.com

Visit our Customer Service website at
walkeredison.com/pages/customer-service

We are available to help Monday -Thursday 8am-5pm, Friday
8am-3pm MST

For details on Assembly Videos, Assembly Instructions,
Replacement Parts, and Customer service,

SCAN HERE

