



# Multifunctional storage

## Assembly Instructions

we recommend using the included manual installation tool for assembly.  
If you choose to use a power drill, please set it to the lowest torque setting to prevent over-tightening, which may damage the wooden panels.




# Parts List




X1

X1

# Hardware




A x 64sets




Ø15X9.5MM

B x 64sets




Ø8 x 30MM

C x 46pcs




Ø6 x 30MM

D x 6pcs




3.5 x 12MM

E x 56pcs




3.5 x 35MM

F x22pcs




M4 x 16MM

G x 5pcs




300MM

H x 2sets




3.5 x 12MM


I x36pcs




J x 1sets




K x 5sets




(L) x 4sets



(M) x 2sets



















N x 1sets










O x 1sets








## ASSEMBLY MATERIAL

Item no.	Reference Image	Qty.
①		X1
③		X1
⑤		X2
⑦		X1
⑨		X1
⑪		X1
⑬		X2
⑮		X2

Item no.	Reference Image	Qty.
②		X1
④		X1
⑥		X1
⑧		X1
⑩		X1
⑫		X1
⑭		X2
⑯		X2

## ASSEMBLY MATERIAL

Item no.	Reference Image	Oty.
<b>17</b>		X2
<b>19</b>		X1
<b>21</b>		X1
<b>23</b>		X1
<b>25</b>		X1
<b>27</b>		X1
<b>29</b>		X1

Item no.	Reference Image	Oty.
<b>18</b>		X1
<b>20</b>		X1
<b>22</b>		X1
<b>24</b>		X1
<b>26</b>		X1
<b>28</b>		X1
<b>30</b>		X1


# Step 1

(E)

Ø3.5\*12mm  
4X


(H)

300MM CL  
2X





Install first rail on the left side of board.

Step:1




Step:2



Install first rail on the right side of board.

## Step 2

A



6X

B








6X

C




Ø8\*30mm

4X



## Step 3

(H)




HX1

(E)




Ø3.5\*12mm  
2X



## Step 4

(H)




HX1

(E)







Ø3.5\*12mm  
2X
















## Step 5











## Step 6







## Step 7







## Step 8







## Step 9






## Step 10



## Step 11



## Step 12




## Step 13

(C)

Ø8\*30mm  
6X

(F)

Ø3.5\*35mm  
6X



## Step 14

(B)





13X

(C)






Ø8\*30mm






8X




## Step 15



## Step 16








Step:1








Step:2



# Step 17




# Step 18




Clockwise rotation of the bolt increases the door hinge height;  
counterclockwise rotation of the bolt decreases the door hinge height.

Loosen the screw to adjust  
the length of the door hinge




X2




Hinge of big bend

Clockwise rotation of the bolt increases the door hinge height;  
counterclockwise rotation of the bolt decreases the door hinge height.

Loosen the screw to adjust  
the length of the door hinge








X1








Hinge with a medium bend



# Step 19




# Step 20









Step:1





Step:2





## Step 21



## Step 22



## Step 23



The furniture must permanently be fixed to the wall using the provided anti-tipping device to prevent it from tipping over.

- Mark the drill positions on the wall with a pencil.
- Drill a small hole on the marked positions.
- Insert a wall anchor into the drilled hole.
- Fix the anti-tipping strap to the wall using the provided screws.