




























Large Record Storage Cube Bookcase  
CF1129



PARTS LIST


A2		B2		C2		D2		E2	
Top Panel 1 PC		Bottom Panel 1 PC		Left Panel 1 PC		Right Panel 1 PC		Fixed Shelf Panel 1 PC	
F2		G2		H2		I2		J2	
Partition Panel 2 PCS		Upper Back Panel 1 PC		Lower Back Panel 1 PC		Metal Leg Frame 2 PCS		Metal Bar 4 PCS	
K									
Cover 6 PCS									

## HARDWARE LIST

#1  1/4"*12mm Bolt 14 PCS (Extra 1)	#2  7*38mm Screw 8 PCS (Extra 1)	#3  Cam Bolt 12 PCS (Extra 1)	#4  Cam Lock 12 PCS (Extra 1)	#5  8*30mm Wood Dowel 20 PCS (Extra 1)
#6  Back Bracket 14 PCS (Extra 1)	#7  3*15mm Short Screw 14 PCS (Extra 1)	#8  Binding Post 6 SETS (Extra 1)	#9  Ø3.0*15mm Round Head Screw 5 PCS (Extra 1)	#10  Cam Sticker 12 PCS (Extra 1)
#11  M2 Small Allen Wrench 1 PC	#12  M4 Allen Wrench 1 PC	#13  Safety Strap Kit 2 SETS		

## ADDITIONAL TOOLS (Not Provided)


Note: It is not recommended to use power tools during assembly.




Phillips Head Screwdriver

Note: Wood dowels are intended for alignment. Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.


Step 1. Attach covers (part K) to back panels (parts G2 & H2) using binding posts (part #8) and small allen wrench (part #11).



#8  x 6  
 #11  x 1


Step 2. Screw cam bolts (part #3) into panels (parts A2, C2 & D2) using phillips head screwdriver.

Note: Do not over tighten cam bolts. Stop tightening once threads on cam bolt are no longer visible.





#3  x 12



Step 3. Insert partition panels (part F2) to fixed shelf panel (part E2).



Step 4. Attach left panel (part C2) and right panel (part D2) to fixed shelf panel (part E2) using cam locks (part #4), wood dowels (part #5) and phillips head screwdriver.


Note: Cam locks must rotate a full 180°. See pictured insert.




#4		x 4
#5		x 4

Step 5. Attach top panel (part A2) to assembled unit (parts C2, D2 & F2) using cam locks (part #4), wood dowels (part #5) and phillips head screwdriver.


Note: Cam locks must rotate a full 180°. See pictured insert.




Step 6. Insert upper back panel (part G2) and lower back panel (part H2) to assembled unit (parts A2, C2 & D2).




Step 7. Attach bottom panel (part B2) to assembled unit (parts C2, D2, F2 & H2) using screws (part #2), wood dowels (part #5) and allen wrench (part #12).




Step 8. Insert metal leg frames (part I2) into metal bars (part J2). Secure metal bars (part J2) and metal leg frames (part I2) using bolts (part #1) and allen wrench (part #12).



Step 9. Attach assembled unit (parts I2 & J2) to bottom panel (part B2) using bolts (part #1) and allen wrench (part #12).



Step 10. Carefully turn unit upright. Secure back brackets (part #6) to back panels (parts G2 & H2) using short screws (parts #7) and phillips head screwdriver. Secure back panels (parts G2 & H2) using round head screws (part #9) and phillips head screwdriver.








Step 11. Using cam stickers (part #10) cover all cam locks (part #4).







NOTE: It is important to adjust levelers once fully assembled and upright. Extend adjustable leveler until it's firmly in contact with the floor. If relocating, adjust leveler as needed until it's firmly in contact with the floor in new location.

Important: Safety strap kit (part #13) must be installed to prevent tipping damage and/or injury.



#10  x 12




#13	A	B	C	D	E
			 8*3*15mm	 8*4*35mm	
Safety Strap Kit 2 SETS	Wall Anchor 2 PCS	Bracket 4 PCS	Short Screw 2 PCS	Long Screw 2 PCS	Safety Wall Strap 2 PCS

## SAFETY WALL STRAP INSTALLATION

Note: It is highly recommended to install this safety strap kit to prevent tipping, damage and/or injury.

1. Insert short screw (C) and safety wall strap (E) through bracket (B) and attach to top panel (part A2) using phillips head screwdriver.
2. Drill a 1 1/32" hole where you want to secure the unit. The drilled hole will be at the same height as the hole in top panel (part A2) where bracket (B) is attached. Tap wall anchor (A) into the hole.
3. Insert long screw (D) and safety wall strap (E) through bracket (B) into wall anchor (A) using phillips head screwdriver.

Note: This item is not intended for clothing storage use.



### ⚠ WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.



This is a permanent label.  
Do not remove!