
# STARFISH 5" **CONTROL PANEL**

Product Manual

#### Product Description

The Starfish 5" Smart Control Panel provides Gateway functions, interactive functions, and scene panel functions. It is installed in the Junction Box, replacing existing switches. The user can control the smart devices in the home via the Smart Control Panel.



#### Product Installation

Installation preparation


- 1) This product requires a neutral wire, please prepare the neutral wire in advance.
- $\ensuremath{\text{\textcircled{2}}}$  This product is connected to the network through Wi-Fi or Ethernet, please prepare the Wi-Fi network or Ethernet cable in advance.
- $\ensuremath{\ensuremath{\Im}}$  If you need to use the relay, RS485, security network port of this product, please arrange the relevant cables in advance.  $\ensuremath{\textcircled{4}}$  In order to ensure electricity safety and wireless

performance, it is highly recommended to use a


standard plastic box for installation and use. ⑤ Recommended tools: Philips head screwdriver, test pen, electrical tape and other tools, please do not install with electricity on.

## Installation Instructions

- Turn off the main power switch, and use a test pen to confirm that the live wire in the box is not live.
- . Remove the front panel from the back base.




#### Wiring Instructions



#### • Check the wiring to make sure that the copper wire is in good contact with the terminal and there is no exposed wire.

- After fixing the base to the box with mounting screws, buckle back the panel.
- Please note that the screws should not be tightened too tight during the installation process to avoid deformation or damage to the screen or hardware.
- If you encounter any issues with the installation, do not press too hard to force the installation. You should level the wall first and check the bracket.
- The product needs to be installed in an outlet box that meets U.S. and Canadian standards, such as ANSI/UL 514C, ANSI/UL 514A.



## Quick Setup

Download and open the app

Search for "SATCO Starfish" App in the App Store or scan the QR code on the outer packaging/instructions to download and install the App.

For the first-time use, please click the "Register" button to register an account; if you already have an account, click the "Login" button.



Scan the QR code to download "Starfish"App \*App is subject to the actual released

#### Commission settings

1. Install the device according to the installation guide. Turn on the power, and wait for the device to initiate. Connect to the network according to the instructions on

2. Open the Starfish App, then scan the QR code on the Control Panel to configure the network (as shown in the figure below), and perform related operations according to the instructions on the device interface after the commission is successfully finished.



\*The QR code is based on the Control Panel

## Function introduction

Device/Scene overview: STARFISH 5" CONTROL PANEL will automatically acquire the device and scene list from your Starfish Account.

Voice control: please find the voice entry in the Smart Control Panel page of Starfish App, and you could perform voice control after logging in. Gateway function: enter the pairing screen in the Smart

Control page of Starfish App, and add Zigbee

Setting: slide down at the top of the Control Panel to go to the Settings Panel.

## Product specifications

	Product name	STARFISH 5" CONTROL PANEL
	Product model	S11575
	Input	100-240V~, 50/60Hz, 5A MAX
	Wireless protocol	Wi-Fi, Zigbee, BLE
	Max load ratings	Tungsten/ Incandescent 200W Dimmable CFL/LED 200W Ballast/Fluorescent 200VA
	Working temperature	0°C~40°C
	Working Humidity	5%~90%RH non-condensing
	Product size	2.8"x5"x0.4" (base excluded) 2.8"x5"x1.4" (base included)
	Net weight	0.6 LB

# WARNINGS

- 1. In order to ensure the correct use of this product, it must be installed, maintained and disassembled by a professional electrician.
- 2. Before installing and disassembling this product, the main power switch must be cut off to prevent electric shock. 3. This product should be kept away from fire and water
- sources during installation and use, and should not be used in humid environments (such as bathrooms). 4. Confirm that the voltage is in line with the working voltage of this product before use, and do not insert the PoE network cable into the network port.
- 5. Do not repair the product by yourself. Any modification or flashing of the product without authorization will void the warranty.
- 6. The product needs to be installed by technicians. The installation environment is concrete wall.
- 7. The distribution box must be plastic and non-hygroscopic material, with a minimum fire-resistance rating of
- 8. There should be no other metal conductive objects in the distribution box
- 9. The distance between the opening of the product body and the opening of the junction box should be at least 1

- 10. This device needs to be protected by a 5A circuit
- 11. The switched circuits cannot be used in SELV/PELV 12. The product must be installed in an area not more than
- 6 FT & 6 IN above the ground.



Class II equipment. Equipment in which protection against electric shock does not rely on basic insulation only, but in which a supplementary safeguard is provided, there being no provision for protective earthing or reliance upon installation conditions.

~ a.c. Nature of the supply voltage.



This product must not be disposed of as normal household waste, in accordance with EU directive for waste electrical and electronic equipment (WEEE-2012/19/EU). Instead, it should be disposed of by returning it to the point of sale, or to a municipal recycling collection point.

The device could be used with a separation distance of 8 INCH to the human body.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The users manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. In cases where the manual is provided only in a form other than paper, such as on a computer disk or over the Internet, the information required by this section may be included in the manual in that alternative form, provided the user can reasonably be expected to have the capability to access information in that

(b) For a Class B digital device or peripheral, the instructions furnished the user shall include the following or similar statement, placed in a prominent location in the text of the

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna. - Increase the separation between the equipment and
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 8 INCH from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for satisfying RF exposure

#### Warranty Policy

This Satco Products, Inc. product is warranted to be free from defects in materials and workmanship for a period of 1 year from date of original purchase. The warranty does not cover damage caused by abuse, misuse, improper environmental conditions, wrong installation or shipping damage. If this does not last, return with proof or purchase, register receipt with your name & address. For replacement. This replacement is the sole remedy available and liability for incidental or consequential damages is hereby expressly excluded. This warranty shall not apply to any product that is found to have been improperly installed, set-up, or used in any way not in accordance with the instructions supplied with the

Satco does not warrant and specially disclaims any warranty, whether expressed or implied, of fitness for a particular purpose, other than the warranty contained herein. Satco specifically disclaims any liability and shall not be liable for any consequential or incidental loss or damage, including any labor / expense costs involved in the replacement or repair of said product.

## Non-warranty regulations

1. Unauthorized maintenance, misuse, collision, negligence, abuse, liquid ingress, accident, alteration, incorrect use of non-original accessories, or tearing off/altering of labels or anti-counterfeiting marks. 2. Expiration of validity period of the warranty services of repair, replacement and refund.

the product's own design, technology, manufacturing,

3. Damage caused by major force. 4. Other damages or malfunctions that are not caused by

quality and other issues.