



ASSEMBLY INSTRUCTION #2239

SOFA



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS

1# 1 PC	2# 1 PC	3# 1 PC	4# 1 PC	5# 1 PC	6# 1 PC	7# 1 PC	8# 1 PC
9# 4 PC	10# 1 PC	11# 1 PC	12# 4 PC	13# 1 PC	14# 1 PC	15# 2 PC	

Hardware

A# 12 PCS	B# 24 PCS	C# 24 PCS	D# 1 PC	E# 8 PCS

Sofa compression finishing manual;

1: Use scissors to carefully cut through the outer plastic wrap (to avoid scratching the inner fabric) and remove all outer bags, cartons, and straps. Keep the instructions;

2: Gently remove the seat/seat bag from the inner plastic compression bag;




3: Place the seat bag/lean bag fully unfolded and placed in the correct position on the sofa frame;

4: Wait patiently for the rebound; This is the key! It takes 24-72 hours (or more) for the seat bag/upholstery to fully regain its full shape and comfort.

Keep them unfolded without squeezing or pressing them hard.

5: During or after recovery, gently pat and knead the surface and edges of the seat/backpack to help evenly distribute the inner padding and eliminate transport indentations. If there are folds, try gently stretching the fabric in different directions to flatten it.

STEP :Packing Details




ASSEMBLY INSTRUCTION #2239

STEP 1

9# 4 PC	10# 1 PC	11# 1 PC	12# 4 PC	13# 1 PC	14# 1 PC	15# 2 PC




Sofa compression finishing manual;



Carefully open the compression bag.

4: Wait patiently for the rebound; This is the key! It takes 24-72 hours (or more) for the seat bag/upholstery to fully regain its full shape and comfort. Keep them unfolded without squeezing or pressing them hard.
5: During or after recovery, gently pat and knead the surface and edges of the seat/backpack to help evenly distribute the inner padding and eliminate transport indentations. If there are folds, try gently stretching the fabric in different directions to flatten it.


STEP 2




A# 12 PCS	B# 24 PCS	C# 24 PCS	D# 1 PC

ASSEMBLY INSTRUCTION #2239


STEP 3




STEP 4



STEP 5




STEP 6




ASSEMBLY INSTRUCTION #2239


STEP 7



STEP 8



STEP 9



STEP 10

