

















CROSLEY

FURNITURE

















Sideboard CF4231



PART LIST


A	B	C	D	E
				
Top Panel 1 PC	Bottom Panel 1 PC	Left Panel 1 PC	Right Panel 1 PC	Middle Partition Panel 1 PC
F	G	H	I	J
				
Left Partition Panel 1 PC	Right Partition Panel 1 PC	Middle Shelf 2 PCS	Side Shelf 2 PCS	Middle Back Panel 2 PCS
K	L	M	N	O
				
Side Back Panel 2 PCS	Cover 8 PCS	Leg 7 PCS	Middle Door 2 PCS	Side Door 2 PCS

HARDWARE LIST

#1		#2		#3		#4		#5	 6 x 8 mm
Cam Lock 26 PCS (Extra 1)	Cam Bolt 26 PCS (Extra 1)	Cam Sticker 26 PCS (Extra 1)	Plastic Dowel 43 PCS (Extra 1)	Varianta Screw 8 PCS (Extra 1)					
#6		#7		#8		#9		#10	
10 x 33.5 mm	4 x 10 mm	6 x 30 mm	Shelf Pin 16 PCS (Extra 1)	Push To Open 4 PCS					
Confirmat Screw 10 PCS (Extra 1)	Euro Screw 16 PCS (Extra 1)	Bolt 7 PCS (Extra 1)							
#11		#12		#13		#14		#15	
Curve Hinge 4 PCS	Straight Hinge 4 PCS	Binding Post 8 SETS (Extra 1)	Allen Key 1 PC	Wall Anchor 2 PCS					
#16									
Safety Strap Kit 2 SETS									

ADDITIONAL TOOLS (Not Provided)

NOTE: It is not recommended to use power tools during assembly



Phillips Head Screwdriver


NOTE: Lay all parts on a soft surface, such as carpet to assemble unit.

NOTE: Plastic dowels are intended for alignment. Additional clearance between plastic dowel and pre-drilled hole is intentional for ease of assembly.

IMPORTANT NOTE: WE RECOMMEND AT LEAST TWO PEOPLE WORK TOGETHER TO ASSEMBLE UNIT.


Step 1. Screw cam bolts (part #2) into top panel (part A) using phillips head screwdriver. Attach push to opens (part #10) to top panel (part A) using varianta screws (part #5) and phillips head screwdriver.

Note: Do not overtighten cam bolts. Stop tightening once threads on cam bolt are no longer visible.




Step 2. Screw cam bolts (part #2) into bottom panel (part B) using phillips head screwdriver. Insert cam locks (part #1) and plastic dowels (part #4) into left panel (part C) and right panel (part D).


Note: Do not overtighten cam bolts. Stop tightening once threads on cam bolt are no longer visible.




Step 3. Insert cam locks (part #1) into partition panels (parts E, F & G).
Insert plastic dowels (part #4) into partition panels (parts E, F & G) and legs (part M).



Step 4. Attach covers (part L) to back panels (parts J & K) using binding posts (part #13), allen key (part #14) and phillips head screwdriver. Insert cam locks (part #1) and plastic dowels (part #4) into back panels (parts J & K).




Step 5. Attach legs (part M) to bottom panel (part B) using bolts (part #8) and allen key (part #14).




Step 6. Attach panels (parts C, D, E, F & G) to top panel (part A).
Use phillips head screwdriver to turn the cam locks (part #1) clockwise to fasten.

Note: Cam locks must rotate a full 180°. See pictured insert.




Step 7. Attach back panels (parts J & K) to top panel (part A).
Use phillips head screwdriver to turn the cam locks (part #1) clockwise to fasten.

Note: Cam locks must rotate a full 180°. See pictured insert.




Step 8. Attach bottom panel (part B) to assembled unit (parts C, D, E, F, G, J & K) using confirmat screws (part #6) and phillips head screwdriver.
Use phillips head screwdriver to turn the cam locks (part #1) clockwise to fasten.


Note: Cam locks must rotate a full 180°. See pictured insert.




Step 9. Use cam stickers (part #3) to cover all cam locks (part #1). Place shelf pins (part #9) into desired position and slide adjustable shelves (parts H & I) into place.




Step 10. Attach curve hinges (part #11) to middle doors (part N) using euro screws (part #7) and phillips head screwdriver.




Step 11. Attach middle doors (part N) with curve hinges (part #11) to partition panels (parts F & G) using phillips head screwdriver.



Step 12. Attach straight hinges (part #12) to side doors (part O) using euro screws (part #7) and phillips head screwdriver.



Step 13. Attach side doors (part O) with straight hinges (part #12) to side panels (parts C & D) using phillips head screwdriver.










Step 14. Adjust push to open (part #10) until door can successfully open. See pictured insert.

Note: It is important to adjust levelers once fully assembled and upright.

Extend adjustable leveler until it's firmly in contact with the floor. If relocating, adjust levelers as needed until it's firmly contact with the floor in new location.

Important: Safety strap kits (part #16) must be installed to prevent tipping, damage and/or injury.




#16	A	B	C	D	#15
		 4 x 15 mm	 8 x 50 mm		
Safety Strap Kit 2 SETS	Bracket 4 PCS	Short Screw 2 PCS	Long Screw 2 PCS	Safety Wall Strap 2 PCS	Wall Anchor 2 PCS

SAFETY WALL STRAP INSTALLATION

NOTE: It is highly recommended to install this safety strap kit to prevent tipping, damage and/or injury.

1. Insert short screw (B) and safety wall strap (D) through bracket (A) and attach to top panel (part A) using phillips head screwdriver.
2. Drill 1 1/32" hole where you want to secure the unit. The drilled hole will be at the same height as hole in top panel (part A) where bracket (A) is attached. Tap wall anchor (part #15) into the hole.
3. Insert long screw (C) and safety wall strap (D) through bracket (A) into wall anchor (part #15) using phillips head screwdriver.


Note: This item is not intended for clothing storage use.



ADJUST YOUR DOORS TO MAKE THE GAPS MORE EVEN (OPTIONAL).


STEP 1

Open the door




STEP 2

Adjust the gap between door panel and side panel




Loosen the screw indicated a little, adjust the hinge to right position (see step 2a & 2b), then tighten the screw.

STEP 2a MOVE DOOR IN



Push the hinge back a little.


STEP 2b MOVE DOOR OUT



Pull the hinge forward a little.


STEP 3

To adjust the gap between two door




Loosen or tighten the screw indicated a little to adjust the gap between doors panels (see step 3a & step 3b)

STEP 3a MOVE DOOR RIGHT



Turn the screw clockwise a little as shown to make the gap small.

STEP 3b MOVE DOOR LEFT



Turn the screw counterclockwise a little as shown to make the gap big.

PO#74675

CF4231

MADE IN INDONESIA