














CROSLEY

FURNITURE



Sideboard CF4229



PART LIST


| | | | | |
|--|--|---|---|---|
| A  | B  | C  | D  | E  |
| Top Panel | Bottom Panel | Left Panel | Right Panel | Partition Panel |
| 1 PC | 1 PC | 1 PC | 1 PC | 1 PC |
| F  | G  | H  | I  | J  |
| Adjustable Shelf | Back Panel | Left Door | Right Door | Leg |
| 2 PCS | 2 PCS | 2 PCS | 2 PCS | 4 PCS |
| K  | L  | | | |
| Center Leg | Cover | | | |
| 1 PC | 2 PCS | | | |

HARDWARE LIST

| | | | | |
|---|---|---|--|--|
| #1  Ø8*30mm | #2  Ø6*35mm | #3  Ø15*12mm | #4  Ø3.5*12mm | #5  Ø3.5*15mm |
| Wood Dowel | Cam Bolt | Cam Lock | Short Screw | Medium Screw |
| 12 PCS (Extra 1) | 12 PCS (Extra 1) | 12 PCS (Extra 1) | 32 PCS (Extra 1) | 48 PCS (Extra 1) |
| #6  Ø1/4"*2" | #7  Ø1/4" | #8  Ø1/4" | #9  M3*4mm | #10  Ø6*10*13mm |
| Bolt | Flat Washer | Spring Washer | Binding Post | Shelf Holder |
| 4 PCS (Extra 1) | 4 PCS (Extra 1) | 4 PCS (Extra 1) | 2 SETS (Extra 1) | 8 PCS (Extra 1) |
| #11  Ø35mm | #12  Ø35mm | #13  2.5mm | #14  4mm | #15  14*10mm |
| Full Curve Hinge | Half Curve Hinge | Small Allen Wrench | Allen Wrench | Back Bracket |
| 4 PCS | 4 PCS | 2 PCS | 1 PC | 20 PCS (Extra 1) |
| #16  Ø3*16mm | #17  34*34*1.5mm | #18  Ø20mm | #19  | |
| Long Screw | Metal Plate | Cam Sticker | Safety Strap Kit | |
| 20 PCS (Extra 1) | 4 PCS | 12 PCS (Extra 1) | 2 SETS | |

ADDITIONAL TOOLS (Not Provided)

Note: It is not recommended to use power tools during assembly.




Phillips Head Screwdriver

Note: Wood dowels are intended for alignment. Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.

Step 1. Screw cam bolts (part #2) into panels (parts A, B, C & D) using phillips head screwdriver.

Attach metal plates (part #17) to panels (parts C & D) using short screws (part #4) and phillips head screwdriver.

Note: Do not overtighten cam bolts. Stop tightening once threads on cam bolt are no longer visible.








#2  x 12

#4  x 16


#17  x 4

Step 2. Attach legs (part J) to bottom panel (part B) using spring washers (part #8), flat washers (part #7), bolts (part #6) and allen wrench (part #14). Screw in center leg (part K) into designated hole as shown.




- | | | |
|-----|---|-----|
| #6 |  | x 4 |
| #7 |  | x 4 |
| #8 |  | x 4 |
| #14 |  | x 1 |

Step 3. Attach top panel (part A) and bottom panel (part B) to partition panel (part E) using wood dowels (part #1), cam locks (part #3) and phillips head screwdriver.
Note: Cam locks must rotate a full 180°. See pictured insert.




Step 4. Insert back panels (part G) into grooves of assembled unit (parts A, B & E).




Step 5. Attach left panel (part C) and right panel (part D) to panels (parts A, B & G) using wood dowels (part #1), cam locks (part #3) and phillips head screwdriver.

Note: Cam locks must rotate a full 180°. See pictured insert.




Step 6. Secure panels (parts C & D) to top panel (part A) using short screws (part #4) and phillips head screwdriver.




#4  x 16


Step 7. Attach covers (part L) to back panels (part G) using binding posts (part #9) and small allen wrench (parts #13).





Step 8. Place shelf holders (part #10) into desired position and slide adjustable shelves (part F) into place.




Step 9. Attach full curve hinges (part #11) to doors (parts H & I) using medium screws (part #5) and phillips head screwdriver.




- #5  x 8
- #11  x 4


Step 10. Attach half curve hinges (part #12) to doors (parts H & I) using medium screws (part #5) and phillips head screwdriver.



Step 11. Attached left door (part H) with full curve hinges (part #11) to left panel (part C) using medium screws (part #5) and phillips head screwdriver.
Attached left door (part H) with half curve hinges (part #12) to partition panel (part E) using medium screws (part #5) and phillips head screwdriver.




Step 12. Attach right door (part I) with full curve hinges (part #11) to right panel (part D) using medium screws (part #5) and phillips head screwdriver.
Attach right door (part I) with half curve hinges (part #12) to partition panel (part E) using medium screws (part #5) and phillips head screwdriver.



Step 13. Secure back brackets (part #15) at the corner of back panels (part G) using long screws (part #16) and phillips head screwdriver.

Note: It is important to adjust levelers once fully assembled and upright. Extend adjustable leveler until it's firmly in contact with the floor. If relocating, adjust leveler as needed until it's firmly in contact with the floor in new location.





#15  x 20

#16  x 20

Step 14. Using cam stickers (part #18) cover all cam locks (part #3).






Important: Safety strap kits (part #19) must be installed to prevent tipping damage and/or injury.



#18



x 12


| | | | | |
|---|---|---|--|---|
| #19 | a | b | c | d |
|  |  |  |  |  |
| Safety Strap Kit 2 SETS | Wall Anchor 2 PCS | Short Screw 2 PCS | Long Screw 2 PCS | Safety Wall Strap 2 PCS |

SAFETY WALL STRAP INSTALLATION

Note: It is highly recommended to install this safety strap kit to prevent tipping, damage and/or injury.


1. Insert short screw (b) and safety wall strap (d) and attach to top panel (part A) using phillips head screwdriver.
2. Drill a 11/32" hole where you want to secure the unit. The drilled hole will be at the same height as the hole in top panel (part A) where the safety wall strap (d) is attached. Tap wall anchor (a) into the hole.
3. Insert long screw (c) and safety wall strap (d) into wall anchor (a) using phillips head screwdriver.

Note: This item is not intended for clothing storage use.



⚠ WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:




- ALWAYS install tipover restraint provided.
- For use with televisions weighing 50lbs(23kg) or less. Use with heavier televisions may result in instability causing tip-over resulting in death or serious injury.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time. Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!

ADJUST YOUR DOORS TO MAKE THE GAPS MORE EVEN (OPTIONAL).


STEP 1

Open the door




STEP 2

Adjust the gap between door panel and side panel




Loosen the screw indicated a little, adjust the hinge to right position (see step 2a & 2b), then tighten the screw.

STEP 2a MOVE DOOR IN



Push the hinge back a little.


STEP 2b MOVE DOOR OUT



Pull the hinge forward a little.


STEP 3

To adjust the gap between two door




Loosen or tighten the screw indicated a little to adjust the gap between doors panels (see step 3a & step 3b)

STEP 3a MOVE DOOR RIGHT



Turn the screw clockwise a little as shown to make the gap small.

STEP 3b MOVE DOOR LEFT



Turn the screw counterclockwise a little as shown to make the gap big.