


Hall Tree

Assembly Instructions -Please keep for future reference



Dimensions
















Width-59 inch
Depth-16 inch
Height-77 inch

Important -Please read these instructions fully before starting assembly


Components -Fittings

Please check you have all the panels listed below

Note:The quantitie below are the correct amount to complete the assembly.In some cases more fittings may be supplied than are required.

<div><div>A</div><div></div><div>Cam Bolt x 79 +2</div></div>	<div><div>B</div><div></div><div>Lock x 80 +2</div></div>	<div><div>C</div><div></div><div>Dowel x 85 +2</div></div>	<div><div>D</div><div></div><div>7*50mm Screw x 22 +1</div></div>
<div><div>E</div><div></div><div>3.5*14mm Screw x 12 +1</div></div>	<div><div>F</div><div></div><div>Plastic buckle x 34 +1</div></div>	<div><div>G</div><div></div><div>3*12mm Screw x 34 +1</div></div>	<div><div>H</div><div></div><div>Sticker Cover x 35 +1</div></div>
<div><div>I</div><div></div><div>Clothes hook x 5</div></div>	<div><div>J</div><div></div><div>Anti -tipping device x 2</div></div>	<div><div>K</div><div></div><div>Plastic expansion tube x 2</div></div>	<div><div>L</div><div></div><div>4*50mm Screw x 2</div></div>
<div><div>M</div><div></div><div>Nut x 1</div></div>	<div><div>N</div><div></div><div>Screw arbor x 1</div></div>	<div><div>O</div><div></div><div>Felt pad x 8</div></div>	

Tools required



Phillips screwdriver
(medium &large)




Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure That all bolts and fittings are tightend properly.

WARNING
In order to help prevent overturning – please follow these instructions

To help prevent product toppling over please follow the below steps:-

Use the anti tip stap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose


Using Camlocks

Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.

1


DO NOT OVER TIGHTEN.
NE PAS SERRER EXCESSIVEMENT.



Step 2

Push the male camlock into the entry hole.

2




Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.

3




Step 4

Turn the female camlock clockwise with a screwdriver.


You should feel a click when the camlock is locked in place.

The joint is now secure.

4






























Assembly Instructions




There is 1 box of this product.

N721P347430


<div>①</div> <div>1500*204*24mm</div> <div></div> <div>1PC</div>	<div>②</div> <div>1476*169*15mm</div> <div></div> <div>1PC</div>	<div>③</div> <div>1476*169*15mm</div> <div></div> <div>1PC</div>	<div>④</div> <div>1408*169*15mm</div> <div></div> <div>1PC</div>
<div>⑤</div> <div>276*153*15mm</div> <div></div> <div>2PCS</div>	<div>⑥</div> <div>275.5*45*15mm</div> <div></div> <div>2PCS</div>	<div>⑦</div> <div>1185*147.5*15mm</div> <div></div> <div>2PCS</div>	<div>⑧</div> <div>1020.5*45*15mm</div> <div></div> <div>2PCS</div>
<div>⑨</div> <div>1408*150*15mm</div> <div></div> <div>1PC</div>	<div>⑩</div> <div>1035*100*15mm</div> <div></div> <div>2PCS</div>	<div>⑪</div> <div>1416*283*3mm</div> <div></div> <div>1PC</div>	<div>⑫</div> <div>1043*424.5*3mm</div> <div></div> <div>2PCS</div>
<div>⑬</div> <div>1043*383*3mm</div> <div></div> <div>1PC</div>	<div>⑭</div> <div>1442*400*30mm</div> <div></div> <div>1PC</div>	<div>⑮</div> <div>420.5*370*15mm</div> <div></div> <div>1PC</div>	<div>⑯</div> <div>420.5*370*15mm</div> <div></div> <div>1PC</div>
<div>⑰</div> <div>370.5*354*15mm</div> <div></div> <div>2PCS</div>	<div>⑱</div> <div>370.5*370*15mm</div> <div></div> <div>1PC</div>	<div>⑲</div> <div>1408*370*15mm</div> <div></div> <div>1PC</div>	<div>⑳</div> <div>370*45*15mm</div> <div></div> <div>2PCS</div>
<div>㉑</div> <div>370*45*15mm</div> <div></div> <div>3PCS</div>	<div>㉒</div> <div>1476*45*15mm</div> <div></div> <div>1PC</div>	<div>㉓</div> <div>1476*45*15mm</div> <div></div> <div>1PC</div>	<div>㉔</div> <div>675*180*15mm</div> <div></div> <div>1PC</div>
<div>㉕</div> <div>675*180*15mm</div> <div></div> <div>1PC</div>	<div>㉖</div> <div>1442*50.5*15mm</div> <div></div> <div>1PC</div>	<div>㉗</div> <div>703.5*378.5*3mm</div> <div></div> <div>2PCS</div>	

Assembly Instructions

Step 1




A




Cam Bolt x 15

C




Dowel x 4

Step 2




A



Cam Bolt x 8


C




Dowel x 6

Assembly Instructions

Step 3




A




Cam Bolt x 6

C




Dowel x 18

Step 4




A



Cam Bolt x 4


C




Dowel x 6

Assembly Instructions

Step 5




A




Cam Bolt x 4

C




Dowel x 15

Step 6




A



Cam Bolt x 10


C



Dowel x 26


Assembly Instructions

Step 7




Both sides of the board 14 need to be installed with screws.

A




Cam Bolt x 14

Step 8




A



Cam Bolt x 18


C




Dowel x 10

Assembly Instructions

Step 9




D




7*50mm Screw x 4

Step 10




D




7*50mm Screw x 4

Assembly Instructions

Step 11



B






Lock x 4

step1


step2

step3




Please flip carefully!

Step 12



B






Lock x 7

step1


step2

step3




Assembly Instructions

Step 13




B




Lock x 8


step1



step2



step3




Step 14


third

first


second




step1




step2



step3




B




Lock x 3

M



Nut x 1


N




Screw arbor x 1

Assembly Instructions

Step 15



B






Lock x 18


step1

step2

step3




Step 16




Assembly Instructions

Step 17




B




Lock x 8


step1




step2




step3



Step 18



D



7*50mm Screw x 8

D
D


D
D

D
D


D
D

Assembly Instructions

Step 19




D




7*50mm Screw x 6


Step 20



B




Lock x 4




Assembly Instructions


Step 21




Step 22



B




Lock x 14




Assembly Instructions


Step 23



Step 24



B




Lock x 10

O




Felt pad x 8


step1



step2






step3




Assembly Instructions

Step 25




(B)




Lock x 4

(F)






Plastic buckle x 34

(G)




3*12mm Screw x 34

Step 26




(I)



Clothes hook x 5





(E)




3.5*14mm Screw x 10

Assembly Instructions

Step 27




L




4*50mm Screw x 2

E




3.5*14mm Screw x 2

H




Sticker Cover x 35

J



Anti -tipping device x 2

K



Plastic expansion tube x 2

Step 28

