

ASSEMBLY INSTRUCTION 36 INCH BATH VANITY



Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware. Compare with the parts list to be sure all parts are present. "DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"




- Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe !!! Please assemble on a clean soft
- surface to avoid damage.







Tools Required





IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

PLEASE DO NOT RETURN TO STORE



Please do not return this product to the retailer!! We are able to assist you in ANY way

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.

- 1. Note: This is not a clothing storage cabinet and it is not recommended to use it as a clothing storage cabinet.
- 2. All cabinets come with TRD, stainless steel or our "L-Bracket "when shipped.


Before Installation


Important – Please read these instructions fully before starting assembly

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will
 make the assembly easier, and will help eliminate damage to the product or injury to persons during
 assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.


Cam Lock Assembly Instructions






Identifying the Hardware -Indentify the hardware using the illustrations below.

Part List - N710P293299





Part List - N710P293299





Hardware List- N710P293299


Α	В	С
<u> </u>	<u> </u>	
ø13x1/4"x28mm	ø13x1/4"x50mm	ø1/4"x16x1mm
Hex-Head bolts - 3pcs	Hex-Head bolts - 4pcs	Flat Washer - 3pcs
D	E	F
ø1/4"x10x1.2mm	1/4"Xø10x13mm	ø6x35mm
Lock Washer - 3pcs	Horizontal-Hole bolts(4pcs)	Three in one bolts (15pcs)
G	H	
	€]mmmm>	
ø14.5x12mm	ø8xø4x32mm	
Three in one lock (15pcs)	Round Head Screws - 16pcs	Handle - 4pcs
J	K	L
(S)	Epinninin	
ø5/32"x22mm	ø5/32"x30mm	
Handle Screws - 4pcs	Handle Screws - 4pcs	Damping hinge (2pcs)
M	N	0
	(+) 200000000>	
	ø7xø3.5x12mm	
Damping hinge (2pcs)	Flat head screw (24pcs)	Laminate pad (4pcs)
Р	Q	R
<i>S/////</i>	<u> </u>	€)mmmm>
ø8x30mm	ø6x30mm	ø8xø4x25mm
Wood dowel (17pcs)	Wood dowel (8pcs)	Round Head Screws - 1pc
S	Т	U
(+)		
ø10xø5x60mm	ø12x55mm	4mm
Flat head screw (6pcs)	Plastic stopper (6pcs)	Allen key - 1pc















Draw the spacing between the walls and the No.5, punch holes in the wall, and fix the No.5 to the wall with screws.


Note: Appropriate distance from the top of sink to the ground is 34".













Use the screws to adjust up or down


Use the screws to permanent


Use the screws to adjust left or right


Use the screws to adjust in or out




















Install the sink on the cabinet with glue. Let stand for 24 hours







HINGE ADJUSTMENTS




1 Sideways / Tilt adjustment

Turn the screw

clockwise to move the door further away from
the side of the cabinet


anticlockwise to move the door closer to the
side of the cabinet



2 4 Height adjustment

While supporting the weight of the door, turn the screws

clockwise to move the door up anticlockwise to move the door down



Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw

clockwise to decrease the gap between the door and the cabinet

anticlockwise to increase the gap between the door and the cabinet

