



ASSEMBLY INSTRUCTIONS

TWIN FLOOR BED WITH BOOK SHELF (WITH DOOR)

















MK33819














Detail View




Part List

A  <p>Leg - 1pc</p>	A1  <p>Leg - 1pc</p>
A2  <p>Leg - 1pc</p>	A3  <p>Leg - 1pc</p>
E  <p>Hb. Panel (Top & Bottom) - 2pcs</p>	E1  <p>Fb. Panel (Top & Bottom) - 2pcs</p>
F  <p>Fb. Mid. Panel (Short) - 1pc</p>	F1  <p>Fb. Mid. Panel (Long) - 1pc</p>
J  <p>Fb. Support Bar (Top & Bottom) - 2pcs</p>	K  <p>Fb. Support Bar (Mid.) - 1pc</p>
G  <p>Side Rail Front - 1pc</p>	G1  <p>Side Rail Back - 1pc</p>
H  <p>Door - 1pc</p>	N  <p>Bed Slats - 7pcs</p>

Hardware List


1  M6 x 80mm JCBC (9pcs)	2  M6 x 15mm Barrel Nut (19pcs)	3  M10 x 40mm Wood Dowel (12pcs)
4  Sticker Cap (2pcs)	5  M6 x 65mm JCBC (10pcs)	6  20 x 20 x 233mm Wood Block (1pc)
7  M4 x 25mm CSK Screw (14pcs)	8  M6 x 30mm JCBC-W (6pcs)	9  M6 x 30mm JCBC (2pcs)
10  6 x 24 x 55mm (135°) Hinges (2pcs)	11  10 x 40 x 60mm Lock (1pc)	12  M3.5 x 16mm CSK Screw (14pcs)
13  M4 Allen Key (1pc)		

ASSEMBLY TOOLS REQUIRED (NOT INCLUDED)




PLEASE BE CAREFUL DO NOT DAMAGE THE HOLE POSITION WHEN YOU USE POWER TOOLS !

STEP 1:



STEP 2:


2	3	5	8
4PCS	4PCS	4PCS	6PCS




Note: Part 2 will face up with the "+" mark on it, otherwise it cannot be tightened

STEP 3:


9




2PCS




STEP 4:




STEP 5:





STEP 6:





STEP 7:





10	12
	
2PCS	4PCS



STEP 8:





12

4PCS


STEP 9:

11	12
	
1 PC	6 PCS




STEP 10:

6	7
	
1 PCS	14 PCS



Note: Use Wood Block as a guidance distance between Bed Slats.



Note: Do not lock the screws of the bed slats to the outermost edge of the bed slats, you need to leave a certain space at the edges, otherwise it will cause the board to break. Do not lock the bed slats on the edge of the wood, please hold firmly before screwing, hold it in place with one hand, then lock the screw.