





















CROSLEY

FURNITURE












Record Storage Console CF1160



PART LIST


A 	B 	C 	D 	E 
Left Panel 1 PC	Right Panel 1 PC	Back Rail 1 PC	Top Panel 1 PC	Left Partition Panel 1 PC
F 	G 	H 	I 	J 
Right Partition Panel 1 PC	Left Shelf 1 PC	Front Panel 1 PC	Middle Shelf 1 PC	Right Shelf 1 PC
K 	L 	M 	N 	O 
Bottom Panel 1 PC	Front Rail 1 PC	Left Back Panel 1 PC	Middle Back Panel 1 PC	Right Back Panel 1 PC
P 	Q 	R 	S 	
Support Leg 2 PCS	Cover 2 PCS	Door 2 PCS	Metal Wire 3 PCS	

HARDWARE LIST

<div>#1</div>  <div>Ø8mm*1-1/8"</div>	<div>#2</div>  <div>Ø1/4"*1-1/4"</div>	<div>#3</div> 	<div>#4</div> 	<div>#5</div> 
<div>Wood Dowel</div> <div>43 PCS (Extra 1)</div>	<div>Bolt</div> <div>4 PCS (Extra 1)</div>	<div>Cam Bolt</div> <div>36 PCS (Extra 1)</div>	<div>Cam Lock</div> <div>36 PCS (Extra 1)</div>	<div>Round Head Screw</div> <div>32 PCS (Extra 1)</div>
<div>#6</div> 	<div>#7</div> 	<div>#8</div> 	<div>#9</div>  <div>4mm</div>	<div>#10</div> 
<div>Binding Post</div> <div>2 SETS</div>	<div>Hex Nut</div> <div>12 PCS (Extra 1)</div>	<div>Open Wrench</div> <div>1 PC</div>	<div>Allen Wrench</div> <div>1 PC</div>	<div>Safety Strap Kit</div> <div>2 SETS</div>
<div>#11</div>  <div>Cam Sticker</div> <div>36 PCS (Extra 1)</div>				

ADDITIONAL TOOLS (Not Provided)

Note: It is not recommended to use power tools during assembly.




Phillips Head Screwdriver

Note: Wood dowels are intended for alignment. Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.


Step 1. Attach cam bolts (part #3) to left panel (part A), right panel (part B), back rail (part C), top panel (part D), left partition panel (part E), right partition panel (part F), front panel (part H) and bottom panel (part K) using phillips head screwdriver.

Note: Do not overtighten cam bolts. Stop tightening once threads on cam bolt are no longer visible.





Step 2. Attach left partition panel (part E), right partition panel (part F) to middle shelf (part I) using wood dowels (part #1), cam locks (part #4) and phillips head screwdriver.



Note: Cam locks must rotate a full 180°. See pictured insert.



Step 3. Attach top panel (part D) to back rail (part C) using wood dowel (part #1), cam locks (part #4) and phillips head screwdriver.



Note: Cam locks must rotate a full 180°. See pictured insert.





- #1  x 1
- #4  x 2

Step 4. Attach top panel (part D) to assembled unit (parts E & F) using wood dowels (part #1), cam locks (part #4) and phillips head screwdriver.



Note: Cam locks must rotate a full 180°. See pictured insert.





- #1  x 4
- #4  x 4

Step 5. Attach front panel (part H) to left shelf (part G) using wood dowels (part #1), cam lock (part #4) and phillips head screwdriver.

Note: Cam locks must rotate a full 180°. See pictured insert.






#1  x 2


#4  x 1

Step 6. Attach assembled unit (parts G & H) and right shelf (part J) to assembled unit (parts E & F) using wood dowels (part #1), cam locks (part #4) and phillips head screwdriver.

Note: Cam locks must rotate a full 180°. See pictured insert.






#1  x 6

#4  x 6


Step 7. Attach front rail (part L) to bottom panel (part K) using wood dowels (part #1), cam locks (part #4) and phillips head screwdriver.




Note: Cam locks must rotate a full 180°. See pictured insert.



- | | | |
|----|---|-----|
| #1 |  | x 2 |
| #4 |  | x 3 |


Step 8. Attach bottom panel (part K) to assembled unit (parts E & F) using wood dowels (part #1), bolts (part #2) and allen wrench (part #9).





- | | | |
|----|---|-----|
| #1 |  | x 4 |
| #2 |  | x 4 |
| #9 |  | x 1 |

Step 9. Attach left panel (part A), right panel (part B) to assembled unit (parts C, D, G, H, J, K & L) using wood dowels (part #1), cam locks (part #4) and phillips head screwdriver.


Note: Cam locks must rotate a full 180°. See pictured insert.



- | | | |
|----|--|------|
| #1 |  | x 20 |
| #4 |  | x 14 |


Step 10. Attach support legs (part P) to bottom panel (part K).

Attach metal wires (part S) to bottom panel (part K) using hex nuts (part #7) and open wrench (part #8).



- | | | |
|----|---|------|
| #7 |  | x 12 |
| #8 |  | x 1 |


Step 11. Attach covers (part Q) to middle back panel (part N) and right back panel (part O) using binding posts (part #6) and phillips head screwdriver.




Step 12. Secure back rail (part C) to right panel (part B) and left panel (part A) using cam locks (part #4) and phillips head screwdriver.

Attach left back panel (part M), middle back panel (part N) and right back panel (part O) to assembled unit (parts A, B, C, E, F & K) using round head screws (part 5) and phillips head screwdriver.


Note: Cam locks must rotate a full 180°. See pictured insert.



Step 13. Attach doors (part R) to assembled unit (parts D & K).









Step 14. Using cam stickers (part #11) cover all cam locks (part #4).



Note: It is important to adjust levelers once fully assembled and upright. Extend adjustable leveler until it's firmly in contact with the floor. If relocating, adjust leveler as needed until it's firmly in contact with the floor in new location.

Important: Safety strap kits (part #10) must be installed to prevent tipping damage and / or injury.


#10	A	B	C	D	E
					
Safety Strap Kit 2 SETS	Wall Anchor 2 PCS	Bracket 4 PCS	Short Screw 2 PCS	Long Screw 2 PCS	Safety Wall Strap 2 PCS

SAFETY WALL STRAP INSTALLATION

Note: It is highly recommended to install this safety strap kit to prevent tipping, damage and/or injury.

1. Insert short screw (C) and safety wall strap (E) through bracket (B) and attach to back rail (part C) using phillips head screwdriver.
2. Drill a 11/32" hole where you want to secure the unit. The drill hole will be at the same height as the hole in back rail (part C) where bracket (B) is attached. Tap wall anchor (A) into the hole. Tap wall anchor (A) into the hole.
3. Insert long screw (D) and safety wall strap (E) through bracket (B) into wall anchor (A) using phillips head screwdriver.

Note: This item is not intended for clothing storage use.



⚠ WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!