








Assembly Instruction

SKU CODE:(W509P371982-W509P371983-W509P371984)



The maximum width of the mattress that the bed frame will fit is 60inch, the maximum length is 80inch, and the maximum thickness is 10inch.
Suggested Mattress Size:Queen, Suggested Mattress Thickness:8inch.


(please note that the mattress weight less than 80lbs may cause the feet of the bed frame are off the ground)





Recommended Maximum Weight

WARNING



PLEASE DO NOT RETURN TO STORE



Please do not return this product to the retailer!
We are able to assist you in ANY way

If you find that you have any trouble with assembly or
missing or damaged parts please contact the seller.

General Guidelines

- .Please read the following instruction carefully and use the product accordingly.
- .Please keep this manual and hand it over when you transfer the product.
- .This summary may not include every detail of all variations and considered steps.Please contact us when further information and help are needed.


Notes

- . This unit has been designed to support the maximum loads shown. Exceeding these load limits could cause sagging, instability, product collapse, and/or serious injury.
- .The product is intended for indoor use only. The product must be assembled and used in accordance with the provisions of this manual. Personal injury and/or damage to product may occur if products are used outside of their intended purposes and/or if products have been changed/modified from their original design. The seller does not assume any responsibility or liability with respect to any injury/damage caused by incorrect assembly or improper use.
- .Avoid long-term exposure to humid environments to prevent mildew.
- .Keep the product away from fire sources and high temperatures. Do not expose this product to direct sunlight.
- .Do not place any hot project on the surface of the product.
- .If there are any defective or missing parts after unpacking, please cease assembly immediately and contact us.
- .It is important that each step is performed in correct order to avoid difficulties.
- .Please assemble the item on a spacious surface and do not place the unwrapped product directly on the ground to avoid product damage.
- .Please do not stand or sit on the wooden boards.
- .Please wear gloves during the assembly and/or disassembly process to avoid scratches from any sharp edges.
- .Please match the corresponding part and fitting based on the part number in the manual.
- .If the part does not match with the fitting, please check the pieces as specified in this manual.
- .During assembling, firstly loosely align all screws with corresponding pre-drilled holes and then tighten the screws one by one.
- .Periodically inspect screw tightness while the product is in use.If necessary, retighten to ensure structural integrity.
- .If you accidentally spill water or another liquid on the surface, immediately wipe clean with a dry towel.
- .Please keep the product away from sharp, pointed objects and corrosive substances to prevent product damage.
- .Please place this item on level, solid ground during use.

Warnings

- .During assembly, keep all small parts out of the reach of children.It may be fatal if swallowed or inhaled.
- .Children should not climb or play on this product in order to avoid tipping over the furniture and causing serious injury.
- .To avoid the potential dangers of suffocation, please keep all parts and packaging(film, plastic bags,foam,etc.) away from babies and children.
- .Keep sharp objects and corrosive items away from the product to avoid any damage or injury.
- .Do not shake or move violently during use to avoid tipping over the product.


Parts



WARNING:

To avoid causing unnecessary troubles,
Please check whether the components with corresponding
numbers are installed correctly according to the diagram.

Parts


















WARNING:

To avoid causing unnecessary troubles,
Please check whether the components with corresponding
numbers are installed correctly according to the diagram.


Parts

W509P371982

 <p>⑤ 1600*150*15= 1PCS</p>	 <p>⑥ 1600*50*15= 1PCS</p>	 <p>⑦ 370*50*15= 2PCS</p>	 <p>⑧ 1600*230*15= 1PCS</p>
 <p>⑨ 1600*400*15= 1PCS</p>	 <p>⑩ 1600*400*25= 1PCS</p>	 <p>⑪ 1585*86*15= 1PCS</p>	 <p>⑫ 1585*75*15= 2PCS</p>
 <p>⑬ 902*75*15= 2PCS</p>	 <p>⑭ 902*75*15= 2PCS</p>	 <p>⑮ 902*75*15= 4PCS</p>	 <p>⑳ 300*400*25= 2PCS</p>
 <p>㉒ 300*384*15= 2PCS</p>	 <p>㉓ 300*50*15= 2PCS</p>	 <p>㉔ 300*364*15= 8PCS</p>	

Hardware

W509P371982




A $\Phi 6 \times 28 = 60 + 3 \text{ PCS}$




B $\Phi 15 \times 10 = 132 + 3 \text{ PCS}$



C $\Phi 8 \times 30 = 74 + 3 \text{ PCS}$



D $\Phi 7 \times 50 = 22 + 1 \text{ PCS}$




E1




E2


E $177 \times 9 \times 25 = 2 \text{ PCS}$




F $4 \text{ MM} = 1 \text{ PCS}$



J $\Phi 6 \times 48 = 36 + 2 \text{ PCS}$



K $14 \text{ mm} = 2 \text{ PCS}$



G1

$M8 \times 75 = 4 \text{ PCS}$




G2

$29 \times 15 \times 8 = 8 \text{ PCS}$



G3


$M8 = 8 \text{ PCS}$



G4

$\Phi 38 = 8 \text{ PCS}$

G



H $5 \text{ mm} = 2 \text{ PCS}$




L $13 \times 15 = 16 + 1 \text{ PCS}$




M $\Phi 3.5 \times 14 = 16 + 1 \text{ PCS}$

Parts


W509P371983




① 1067.5*400*25= 1PCS




② 1067.5*400*25= 1PCS




③ 1067.5*400*25= 1PCS




④ 1067.5*400*25= 1PCS




⑫ 912*438*5= 6PCS




⑮ 1067.5*400*15= 1PCS




⑰ 1067.5*400*15= 1PCS



⑱ 1067.5*400*15= 1PCS

























⑳ 1067.5*400*15= 1PCS



㉕ 1034*310*5= 4PCS




















Hardware

W509P371984



 <p>③⑨ 2040*125*50= 1PCS</p>	 <p>④⑩ 2040*125*50= 1PCS</p>	 <p>④① 1986*100*30= 1PCS</p>	 <p>④② 1535*50*49= 2PCS</p>	
 <p>④④ 723*100*30= 2PCS</p>	 <p>④⑤ 723*100*30= 2PCS</p>	 <p>④⑥ 93*45*33= 1PCS</p>	 <p>④⑦ 93*45*33= 1PCS</p>	 <p>④⑧ 500*50*33= 1PCS</p>
 <p>④⑨ 500*50*33= 1PCS</p>	 <p>⑤⑩ 1933*285*14= 1PCS</p>		 <p>⑤① 1933*285*14= 1PCS</p>	
 <p>⑤② 150*100*2.5= 2PCS</p>	 <p>⑤③ 206*50*33= 2PCS</p>	 <p>⑤④ 57*48*26.5= 13PCS</p>	 <p>⑤⑤ 57*29*27= 26PCS</p>	 <p>⑤⑥ 760*52*9= 26PCS</p>
 <p>⑤⑦ 144*123*33= 2PCS</p>	 <p>⑤⑧ 605*22= 4PCS</p>	 <p>⑤⑨ M12*45= 2PCS</p>	 <p>⑥⑩ Φ12*24*1.5= 2PCS</p>	 <p>⑥① 7.8*M6*19= 2PCS</p>



Hardware

W509P371984




 <p>62 M6*20= 8PCS</p>	 <p>63 M6*20= 28+1PCS</p>	 <p>64 M8*20= 20+1PCS</p>	 <p>65 M6*20*Φ8= 4PCS</p>	 <p>66 M6= 2PCS</p>
 <p>67 M8= 8PCS</p>	 <p>68 7.8*M6*35= 2PCS</p>	 <p>69 89*36*25= 4PCS</p>	 <p>70 50*20*20= 2PCS</p>	 <p>71 M8*100= 4PCS</p>
 <p>72 4mm= 1PCS</p>	 <p>73 5mm= 1PCS</p>	 <p>74 M4*16= 16+1PCS</p>	 <p>75 M4*42= 24+2PCS</p>	 <p>76 10mm= 1PCS</p>
 <p>77 M4*20= 26+2PCS</p>	 <p>78 M4*35= 10+1PCS</p>	 <p>79 = 2PCS</p>	 <p>80 M5*100= 4PCS</p>	




Using Camlocks(Single head cam)

Step 1 Connect the male camlock as directed in the assembly instructions using a screwdriver.	1 
Step 3 Insert the female camlock as shown in the instruction. Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.	3 

Step 2 Push the male camlock into the entry hole.	2 
Step 4 Turn the female camlock 180 degrees clockwise with a screwdriver to complete the locking.	4 

Using Camlocks(double heads cam)

Step 1 Push the male camlock into the entry hole as instructed in the assembly manual, ensuring that the exposed portions at both ends of the male camlock are even.	1 
Step 3 Gently turn the placed female camlock 90 degrees clockwise with a screwdriver (it is necessary to ensure that the exposed part of the other end of the male camlock remains unchanged).	3 
Step 5 Turn the female camlock 180 degrees clockwise with a screwdriver to complete the locking.	5 

Step 2 Insert the female camlock at one end first as shown in the instruction. Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.	2 
Step 4 Insert the female camlock into the other end as shown in the instruction. Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.	4 
Step 6 Turn the previously placed female camlock an additional 90 degrees clockwise with a screwdriver to complete the locking.	6 

STEP1

①*1 ②*1 ③*1 ④*1 ⑥*4 ⑦*4


⑧*2

ATTENTION:

This step involves similar panel components.


To prevent assembly errors, please carefully verify the positional relationship of the hole positions in the enlarged diagram.

Also make sure that 1# attaches to 3#, and 2# attaches 4#.




STEP2

⑤*1 ⑥*1 ⑦*2 ①*8 ②*8




Tools Required



STEP3

⑩*1 ⑧*1 ④*4 ③*2

⑥*1



STEP4

⑨* 1

Ⓒ* 8

Ⓓ* 18




Ⓕ* 1

ATTENTION:

There are quite a few components to be installed in this step.

Please pay attention to checking whether all components are complete!

Put them together in the right position before fastening the screws!!





STEP5

(A) * 24



Tools Required





STEP6

②②* 2 ②③* 2 ①A* 4 ①B* 4 ①C* 4



Tools Required




×2

STEP7

②①* 1 ②④* 4 ①B* 12 ①C* 13




Tools Required




STEP8

②1* 1 ②4* 4 ②* 12 ②* 13




Tools Required



STEP9

②5* 4 ②* 2




STEP10

①⑦* 1 ①⑧* 1 ①⑨* 1 ②⑦* 1 ①①* 4 ①②* 4 ①③* 8


ATTENTION:

This step involves similar panel components. To prevent assembly errors, please carefully verify the positional relationship of the hole positions in the enlarged diagram.

Also make sure that 17# attaches to 19#, and 18# attaches to 20#.



Tools Required





STEP11

(A) * 24



Tools Required




STEP12

Ⓑ* 12 Ⓒ* 13




Tools Required




STEP13

Ⓑ* 12 Ⓒ* 13



Tools Required




STEP14

Ⓛ * 16 Ⓜ * 16



Tools Required



WALL ANCHORING REQUIREMENTS & INSTALLATION RECOMMENDATIONS

Important information to read before starting the assembly.
Keep this information for future reference.

IMPORTANT WARNINGS

Risk of serious injuries if the wall bed tips over.

To prevent wall bed from tipping over, mount it permanently to the wall.

Only a qualified person* must carry out the installation and any possible adjustment of the wall bed (including disassembly). If the wall bed is not firmly mounted (anchored) to the wall, it might tip over and cause serious injuries to the installer, users of the bed as well as the people near the bed.

The choice of wall anchoring depends on the type of wall. Use wall anchors suitable for the wall material.



* Qualified person: it is necessary to have a good understanding of the wall structure where the bed is anchored, including the positioning of the wall studs and structural components in the case of a wood or metal structure. If you do not have the necessary skills, make sure that the wall anchoring is done by someone who has the qualifications and required knowledge. When you choose the installer, make sure to comply with all applicable regulations in the province, state or country where the furniture is installed.

IMPORTANT WARNINGS

INSTALLATION AND APPROPRIATE HARDWARE

Using appropriate hardware, all the anchor screws of the wall bed must be firmly secured to the wood or metal studs, the structural components, or a masonry wall.

Only wall anchor screws for wood-frame walls are provided with this bed.


NEVER USE DRYWALL ANCHOR SCREWS OR SECURE THE BED TO DRYWALL

See wall anchoring requirements and installation notes provided in the instruction manual, according to the type of wall, and use the appropriate anchors such as described in this manual.

NUMBER OF SCREWS NEEDED

Two (2) screws are required for each anchor point. Four (4) wall anchor points are necessary for the proper installation of the wall bed. So you need a total of eight (8) wall anchor screws.

THE SCREWS MUST BE VERY WELL ANCHORED TO THE STRUCTURAL COMPONENTS OF THE WALL.




** A CERTIFIED CONSTRUCTION PROFESSIONAL, IN COMPLIANCE WITH APPLICABLE REGULATIONS IN THE PROVINCE, STATE, OR COUNTRY WHERE THE FURNITURE IS INSTALLED.

STEP15




WARNING:

There is a risk of serious injury due to the wall-mounted bed tipping over. To prevent the wall-mounted bed from tipping over, it must be permanently secured to a brick wall. If the wall structure is not masonry, qualified professionals are required to perform the wall anchoring.



Tools Required




- 1, Use a marker pen, a tape measure, and a spirit level to mark positions on the brick wall according to the positions shown in the diagram. Use an electric drill to create 4 A holes and 4 B holes at the marked positions; Hole A has a diameter of 0.4 inches and a depth of 3.6 inches; Hole B has a diameter of 0.4 inches and a depth of 3.9 inches.


71* 4 80* 4



Tools Required



2,
Gently tap the No. 71 expansion bolts into the holes with a hammer until 0.04 inches are exposed outside. Use an adjustable wrench to tighten the nuts on the expansion bolts clockwise with force. Use an adjustable wrench to remove the nuts and anti - slip washers from the expansion bolts.





3,
Gently tap the No. 80 expansion rubber hose into hole B with a hammer until the end ring of the expansion rubber hose is flush with the wall.



⑥9*4 ⑦1*8



Tools Required



4,
Please install the No. 69
iron part strictly according
to the direction shown
in the diagram.




STEP16



WARNING

For your safety

This step requires at least 4 people to complete together. One person is responsible for observing and guiding the moving direction of the cabinet body; two people respectively cooperate on both sides of the cabinet body to move it to the accurate position; and one person is responsible for keeping it upright to prevent the cabinet body from tipping over.



STEP17

⑪* 1 ⑫* 2 ⑬* 2 ⑭* 2 ⑮* 2 ⑯* 6


Ⓑ* 64 Ⓙ* 32

ATTENTION:


This step involves similar panel components. To prevent assembly errors, please carefully distinguish the installation positions according to the component numbers.




Tools Required




1, Pay attention to the installation direction



2,




3,



STEP18

③⑨* 1 ④⑩* 1 ④⑪* 1 ④⑫* 2 ⑥⑬* 16 ⑥⑭* 4




To prevent incorrect installation, please strictly install Panel 41# in the direction shown in the diagram.

STEP19

④④* 2 ④⑤* 2 ④⑥* 1 ④⑦* 1 ⑤②* 2


⑥②* 8 ⑥③* 4 ⑥④* 16 ⑥⑤* 4

⑦②* 1 ⑦③* 1




WARNING

Incorrect assembly of Part 46 and Part 47 will inevitably cause damage to the product during use. Please carefully check whether their installation position and direction are consistent with the diagram.




STEP20



74*16 75*24



Tools Required





Pay attention to the installation direction.
Especially 14# has two guide holes to install
53# stretch across 45#.




74*16

75*24




STEP21

50*1 51*1 66*2 68*2




72*1

Tools Required



When installing 50 # and 51 #,
the foot swing arm should face downwards
and the small swing arm should be on the outer side.
50# and 51# can not be exchanged!!




Please lift the small swing arm here
Then install the screws

STEP22

④⑧* 1 ④⑨* 1 ⑦⑦* 26




Tools Required



STEP23

⑤9*2 ⑥0*2 ⑥1*2

⑦2*1 ⑦6*1




STEP24



WARNING

DO NOT remove the iron straps compressing the hydraulic rods (Part 58) until you have fixed the rods on both sides of the cabinet interior.




Tools Required

This end up

Install the hydraulic lever with the marked area facing upwards.

Swing the bed frame up and down, install 58# onto the bolts of 48# and 49# to get the right position, then lock 67# nuts.



Press down the bed frame appropriately and remove the iron straps of 58#(recommend to wear gloves).

STEP25


⑤3*2 ①E*2

ATTENTION:

Because after removing the iron straps around hydraulic rods, the hydraulic rod will produce tension on the bed frame, due to the subsequent installation, there is no heavy weight on the bed frame, so the bed frame will rebound, therefore, please pay attention to the warning belows.




Tools Required



WARNING



For your safety:

please use no less than 88lbs of weight to press the bed frame in the subsequent installation process, to avoid accidental injury caused by the rebound of the bed frame!



STEP26

⑤④* 13 ⑤⑤* 26 ⑤⑥* 26





STEP27

⑤7*2 ⑦0*2 ⑦8*10




Tools Required



STEP28

79* 2



Final Assembly!