


TV Cabinet

Assembly Instructions - Please keep for future reference



Dimensions

Width-94.4inch

Depth-15.7inch

Height-17.7inch

Important – Please read these instructions fully before starting assembly



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.
- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.



Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure that all bolts and fittings are tightened properly.

WARNING In order to help prevent overturning – please follow these instructions







To help prevent product toppling over please follow the below steps:-

Use the anti tip strap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose

Components-Fittings

Please check you have all the panels listed below


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

			
Cam Bolt x 37+2	Cam Bolt x 51+2	8*30mm Dowel x 30+2	Double headed pole x 7+1
			
Glass clamp x 8+1	Hinge x 6	3.5*14mm Screw x 68+3	Long iron strip x 2
			
Foundation x 12	Light strip x 1	Backboard buckle x 24+1	Screwdriver x 1

Using Camlocks


Step 1

Connect the male camlock as dictated in the assembly instructions using a screwdriver.



Step 2


Push the male camlock into the entry hole.



Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.




Step 4

Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.


The joint is now secure.



Assembly Instructions




There is a protective film,
please tear it off.
s'il vous plaît, déchirez-le.
Il y a un film protecteur,



Assembly Instructions

There are 2 boxes of this product


BOX-1: N721P366141




③ x1




④ x1




⑥ x1




⑦ x1



⑨ x1




⑩ x1




⑪ x1

1184x384x15 578x278x3 578x132.5x3 1200x385x15 1169x384x15 1184x384x15 384x270x15




Hardware Pack X1



⑫ x2




⑮ x1




⑯ x1




⑰ x1



⑲ x1




⑳ x3




㉑ x2

585x278x3 1177x132.5x3 1200x385x15 1200x50x15 1200x50x15 596x297x15 591x360x5


BOX-2: N721P366142



① x1




② x1




⑤ x1



⑧ x2



⑬ x1



⑭ x1

409.5x384x15

570x385x15

425x385x15


417.5x303.5x15

425x385x15


409.5x384x15

Assembly Instructions

Step 1



(A)



Cam Bolt x 2

(B)




Cam Lock x 2

(C)



8*30mm Dowel x 2

Step 2



(A)



Cam Bolt x 2

(B)



Cam Lock x 2


(C)




8*30mm Dowel x 2

Assembly Instructions

Step 3




Step 4



Assembly Instructions

Step 5



Cam Bolt x 4




Cam Lock x 4







8*30mm Dowel x 4

Step 6




Assembly Instructions

Step 7







Step 8





Assembly Instructions

Step 9





Step 10




Assembly Instructions

Step 11





Step 12




Assembly Instructions

Step 13




Cam Bolt x 4



8*30mm Dowel x 4


Step 14





Cam Lock x 4

Assembly Instructions

Step 15




Step 16




Assembly Instructions

Step 17



Step 18



(A)



Cam Bolt x 4

(B)



Cam Lock x 4


(C)



8*30mm Dowel x 4

Assembly Instructions

Step 19




(C)




8*30mm Dowel x 2

(D)



Double headed pole x 6

Step 20




(B)



Cam Lock x 12

Assembly Instructions

Step 21



Long iron strip x 2




3.5*14mm Screw x 32



Foundation x 12

Step 22





Cam Lock x 2



Double headed pole x 1


Assembly Instructions

Step 23



Cam Bolt x 9


Step 24




Cam Lock x 9

Assembly Instructions

Step 25




Step 26 x3




Assembly Instructions

Step 27




When the hinges are installed, you can refer to the pictures to adjust crevice of the doors till it's perfect:

Lorsque les charnières sont installées, vous pouvez vous référer aux photos pour ajuster la crevasse du Portes jusqu'à ce que ce soit parfait :



1. To adjust the doors up and down, please refer to step (a)
2. To adjust the distance between the doors and side panels, please refer to step(b)
3. To adjust the gap between two doors, please refer to step (c)
4. After the adjustment finished, please tight the screws, refer to step (d)

1. Pour régler les portes vers le haut et vers le bas, veuillez vous référer à l'étape (a)
2. Pour régler la distance entre les portes et les panneaux latéraux, veuillez vous référer à l'étape (b)
3. Pour régler l'écart entre deux portes, veuillez vous référer à l'étape (c)
4. Une fois le réglage terminé, veuillez serrer les vis, reportez-vous à l'étape (d)




Assembly Instructions

Step 28


- ① The light strip passes through the small holes on the 1 # and 14 # boards below from the top to the right and is attached to the 16 # and 17 # boards
- ② The USB cable extends from the circular hole on board 6 #

(1) La bande lumineuse passe à travers les petits trous sur les planches 1 # et 14 # ci-dessous de haut en haut à droite et est attaché aux planches 16 # et 17 #

(2) Le câble USB s'étend du trou circulaire de la carte 6 #






Veuillez utiliser la bande lumineuse selon
Vers la bande lumineuseManuel




Please use the light strip according
to the light stripmanual

Step 29



Assembly Instructions

Step 30



Step 31

