



# BED FRAME

SIZE:FULL



Suggestion:

For a simpler and quicker assembly process,  
we recommend that two people work together.

Due to the product's structure, the estimated assembly time is 90 minutes.

## IMPORTANT:

1. Please read the instructions carefully before assembling the product.
2. Before starting the assembly process, check the package carefully to make sure all necessary boards and parts are included.
3. If there are any defective or missing parts after unpacking, please stop assembly and immediately contact us.
4. Before assembly, put all parts and boards in an open area. Ensure that you have the correct parts before screwing them in place.

## ⚠ Warning:

1. During assembly, keep all small objects out of the reach of children, as they may be fatal if swallowed or inhaled.
2. Never allow children to climb or play around the product to protect children from injury caused by the tilting of the product.
3. To avoid the potential dangers of suffocation, please keep all parts and packaging away from children.

## Self equipped tools












Slotted Screwdriver  
(Not included)



Electric Drill  
(Not included)










# Parts Identification 1/4

Not actual size

 Q'ty: 1	 Q'ty: 1	 Q'ty: 1
 Q'ty: 1	 Q'ty: 1	 Q'ty: 2
 Q'ty: 1	 Q'ty: 1	 Q'ty: 1
 Q'ty: 1	 Q'ty: 1	 Q'ty: 1













# Parts Identification 2/4

Not actual size

 13	 14	 15
Q'ty: 1	Q'ty: 1	Q'ty: 1
 16	 17	 18
Q'ty: 1	Q'ty: 1	Q'ty: 1
 19	 20	 21
Q'ty: 1	Q'ty: 1	Q'ty: 1
 22	 23	 24
Q'ty: 1	Q'ty: 1	Q'ty: 1

# Parts Identification 3/4

Not actual size


 Q'ty: 1	 Q'ty: 1	 Q'ty: 1
 Q'ty: 1	 Q'ty: 1	 Q'ty: 1
 Q'ty: 1	 Q'ty: 2 Long	 Q'ty: 2
 Q'ty: 2	 Q'ty: 1	 Q'ty: 10

---

# Parts Identification4/4


Not actual size

37




Q'ty: 2

38




Q'ty: 2

# Hardware List




M8 x 28mm

(A) x 2+1




Ø1/4" x 11mm

(B) x 39+3




Ø1/4" x 28mm

(C) x 7+1




Ø1/4" x 28mm

(D) x 3+1




Ø1/4" x 50mm

(E) x 3+1




Ø5 x 38mm

(F) x 16+1



Ø1/4" x 16mm


(G) x 2+1



Ø1/4" x 16mm


(H) x 12+1

BOLT  
spare: 2




M8 x 50mm

(I) x 4+1





(J) x 8





Ø4 x 12mm


(K) x 6+1




(L) x 20+6




(M) x 4





(N) x 1




(O) x 4




(P) x 3





(Q) x 2



(R) x 4+1












(S) x 2



(T) x 26+2

# Hardware List




★ In many cases, we include additional hardware. So after following the assembly instructions, don't worry if there are still extra pieces left over—they're included as a “just in case” for your convenience.

★ NOTE: When assembling, please do not tighten the screws one by one completely first, until making sure that all the corresponding screws are placed in the right positions.

# Parts Identification

Not actual size



## ATTENTION

When you begin each step, please check carefully whether you have taken the correct parts, so as not to use the wrong parts and cause the wrong assembly.




We recommend that you do not rush to tighten the screws. It is best to tighten the screws to two-thirds first, after all the steps are finished and the position is well adjusted, then tighten.

# Screw Fitting 1:1 Diagram


(F)		$\varnothing 5 \times 38\text{mm}$
(B)		$\varnothing 1/4" \times 11\text{mm}$
(G)		$\varnothing 1/4" \times 16\text{mm}$
(C)		$\varnothing 1/4" \times 28\text{mm}$
(E)		$\varnothing 1/4" \times 50\text{mm}$
(D)		$\varnothing 1/4" \times 28\text{mm}$
(A)		$M8 \times 28\text{mm}$
(I)		$M8 \times 50\text{mm}$
(H)		$\varnothing 1/4" \times 16\text{mm}$
(K)		$\varphi 4 \times 12\text{mm}$
(Z)		$\varphi 3 \times 15\text{mm}$

## STEP 1



**!** Please screws in this step  
need to be tightened




## STEP 2



Proper orientation of CAM LOCK



**!** Please screws in this step  
need to be tightened



## STEP 3

**!** Please screws in this step  
need to be tightened



**V**



**F**


Ø5 x 38mm

**x 4**




**M3**


**x 1**



## STEP 4




Proper orientation of CAM LOCK



**CC**


**x 1**



**U**

**x 4**





**!** Please screws in this step  
need to be tightened



## STEP 5



Please screws in this step  
need to be tightened






## STEP 6






Proper orientation of CAM LOCK



Please screws in this step  
need to be tightened




## STEP 7





Proper orientation of CAM LOCK

**⚠ Please screws in this step need to be tightened**




## STEP 8



Proper orientation of CAM LOCK




**⚠ Please screws in this step need to be tightened**







## STEP 9






Please screws in this step  
need to be tightened






## STEP 10



## STEP 11




## STEP 12




## STEP 13


**⚠** Please screws in this step  
need to be tightened








## STEP 14








**⚠** Please screws in this step  
need to be tightened



## STEP 15




## STEP 16




## STEP 17




Please screws in this step  
need to be tightened



(C) x 1




(Q) x 2



Ø4 x 12mm


(K) x 4




## STEP 18








Please tighten the bolts  
to 80% first, and tighten  
all bolts 100% after all  
parts are assembled.




(O) x 4



## STEP 19



Insert metal plates (Q) under door (19/20) into the groove on panel (18).







Connect door (19/20) metal pulley (O) with bolt(B)





## STEP 20



Please screws in this step  
need to be tightened






## STEP 21




## STEP 22





Please screws in this step  
need to be tightened




## STEP 23







Proper orientation of CAM LOCK







Please screws in this step  
need to be tightened









## STEP 24







## STEP 25



## STEP 26




## STEP 27



## STEP 28





---









Expand the folded portion

## STEP 29

---




## STEP 30




## STEP 31


---




### Assemble the slats




1. Squeeze the clamp (L) tightly.



2. Put the clamp into the gaps.





3. Put the slat (36) into the clamp.



4. Finished.

## STEP 32


---



## STEP 33


---

Expand the drawer frame




X2

## STEP 34






## STEP 35



## STEP 36



Please screws in this step  
need to be tightened








X2

## STEP 37




Please screws in this step  
need to be tightened





To lock the drawer in your preferred position,  
first confirm the desired location by referring to  
STEP 38

X2


## STEP 38




## STEP 39



Please pull the plastic block out of the remote control.



Stick LED strip(Y) underneath board(29), attach the LED strip to the edges.



The LED switch is free to put onto or hidden underneath the board.

---

## **Congratulation:**

Congratulations to you on completing the assembly of the product through your own efforts, you have done a great job.

The assembly of this product may have been difficult, but you still had the patience and perseverance to get it done.

## **Notes:**

1. The product is designed for indoor use only and must be assembled and used according to the provided manual. Modifying or altering the product from its original design may result in personal injury or damage to the product.

## **Product Maintenance:**

1. Please place this item on the level solid ground.
2. Avoid long-term exposure to humid environments to prevent mildew.
3. Keep the product away from high temperature environments or fire sources.
4. If accidentally spill water or another liquid on the surface, immediately wipe with a dry towel.
5. Regularly inspect the tightness of screws while using the product. If necessary, re-tighten to ensure structural stability.