




DJYC2429

ASSEMBLY INTRODUCTION


Needed for Assembly:



2 People




Exploded View



x2



Fittings



CAM-LOCK




WHEN FITTING CAMLOCK
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING QUICKFIT
TURN CLOCKWISE UNTIL SECURE




Quickfit head needs to be in centre

QUICKFIT


**Tighten until shoulder is flush
 with panel. DO not overtighten
 or undertighten (see example
 below)**




Step 1




Step 2




Step 3






Step 4




Step 5




Step 6




Step 7



Step 8




Step 9



M x 4
 $\varphi 4 \times 12 \text{ mm}$

T x 2


Step 10



B x 6
 $\varphi 15 \times 9.5 \text{ mm}$

C x 2
 $\varphi 6 \times 30 \text{ mm}$


Step 11



B x 6
 $\varphi 15 \times 9.5 \text{ mm}$

C x 2
 $\varphi 6 \times 30 \text{ mm}$

Step 12




C x 2
 $\varphi 6 \times 30 \text{ mm}$



D x 2
 $\varphi 5 \times 45 \text{ mm}$

I x 1


Step 13




Step 14




Step 15




Step 16




Step 17




Step 18




Step 19




Step 20




Step 21




Step 22







Step 23






Step 24




Step 25




Step 26



Step 27



Step 28





R x 2 S x 2

Step 29



Customer Attention:



To align doors and control gap in between doors. Product doors may need adjusting during and after assembly.
This can be done by adjusting appropriate screws. See below illustration.



Vertical Door Adjustment:



Loosen both screws on all hinges and lift the door to the desired height.

This allows an even space at the top and bottom between the door and frame.



Lateral Door Adjustment:

If door is hinge bound, (rubbing on frame as you close or open door) loosening screw shown and move the door in appropriate direction. (In or out)



Horizontal Door Adjustment:

Rotate Screw clockwise or anticlockwise.

This will produce an even gap between doors and frame.