



# ASSEMBLY INSTRUCTIONS

SKU CODE: (N710P373591Q)























## Detail View





# Part List


**N710P373591Q**

<b>1</b>  Top Panel - 1pc	<b>2</b>  Bottom Panel - 1 pc	<b>3</b>  Side Panel (Left) - 1 pc
<b>4</b>  Side Panel (Right) - 1 pc	<b>5</b>  Left Panel (Center) - 1pc	<b>6</b>  Centre Panel - 1pc
<b>7</b>  Right Panel (Center) - 1pc	<b>8</b>  Left Shelf - 1pc	<b>9</b>  Right Shelf - 1pc
<b>10</b>  Horizontal Panel (Top) - 1 pc	<b>11</b>  Horizontal Panel (Bottom) - 1 pc	<b>12</b>  Door Panel (Left) - 1pc
<b>13</b>  Front Panel Drawer - 2 pcs	<b>14</b>  Left Panel Drawer - 2 pcs	<b>15</b>  Right Panel Drawer - 2 pcs
<b>16</b>  Back Panel Drawer - 2 pcs	<b>17</b>  Bottom Panel Drawer - 2 pcs	<b>18</b>  Back Panel - 1 pc
<b>19</b>  Back Panel - 1 pc	<b>20</b>  Door Panel (Right) - 1 pc	

# Hardware List N710P373591Q



<b>A</b>  Ø8*30mm	<b>B</b> 	<b>C</b> 
Wood Dowel (28 pcs)	Cam Nut (18 pcs)	Cam Bolt (18 pcs)
<b>D</b>  Ø4 x 45mm	<b>E</b>  Ø4*38mm	<b>F</b>  Ø3.5 x 16mm
Chip Board Screw (10 pcs)	Chip Board Screw (8 pcs)	Chip Board Screw (76 pcs)
<b>G</b>  DR DL 14" (T1.1)	<b>H</b>  5/8"	<b>I</b>  150 X 25mm
Drawer Slide (Black) (2 sets)	Hydraulic Hinges (4 pcs)	Metal Leg (Nikel Black) (7 pcs)
<b>J</b>  3/4"	<b>K</b>  Ø8 X 50mm	<b>L</b>  75 X 40 X 2mm
Nails (56 pcs)	Wood Dowel (6 pcs)	Metal Plate (2 pcs)


## ASSEMBLY TOOLS REQUIRED ( NOT INCLUDED )



PLEASE BE CAREFUL DO NOT DAMAGE THE HOLE POSITION WHEN YOU USE POWER TOOLS !


## STEP 1 :

<b>A</b>	<b>C</b>	<b>K</b>
		
<b>8 PCS</b>	<b>14 PCS</b>	<b>4 PCS</b>






## STEP 2 :

<b>K</b>	<b>A</b>
	
<b>2 PCS</b>	<b>16 PCS</b>




## STEP 3 :


<b>G</b>	<b>F</b>
	
<b>2 SETS</b>	<b>8 PCS</b>




## LEFT DRAWER




## RIGHT DRAWER




STEP 4 :



STEP 5 :



STEP 6 :




**B**



**12 PCS**

STEP 7 :



**D**


**10 PCS**

**B**




**2 PCS**

STEP 8 :



STEP 9 :




REMARK!  
SECURE BOTTOM PANELS WITH METAL PLATES


STEP 10 :


**x2**

<b>F</b>	<b>H</b>
	
<b>8 PCS</b>	<b>4 PCS</b>




STEP 11 :

<b>F</b>	
<b>16 PCS</b>	



STEP 12 :


<b>C</b>	<b>A</b>
	
<b>4 PCS</b>	<b>4 PCS</b>



STEP 13 :


<b>B</b>

<b>4 PCS</b>



STEP 14 :


**x2**




STEP 15 :

**x2**

**E**



**8 PCS**




STEP 16 :


**x2**

<b>G</b>	<b>F</b>
DR	DR
DL	DL

**2 SETS** **8 PCS**



STEP 17:



**STEP 18 :**

