


Serial Number: SDS20-29
R 1.0

Shower Door Installation Instructions



Please do not return the product to the store.
Contact us with any questions.



Model Specific Preparation




REQUIRED:

Verify threshold and wall with a level.

5/16"(8mm) Maximum out of plumb adjustment from top to bottom



PACKAGE CONTENT



PACKAGE CONTENT

PART#	DESCRIPTION	QTY
A	Upper guide rail cover	1
B	Upper Guide Rail	1
C	Roller	4
D	Wall Jamb	2
E	Anti-water strip	4
F	Glass DOOR	2
G	Handle	2
H	Anti-water strip	2













PACKAGE CONTENT

PART#	DESCRIPTION	QTY
I	aluminum end cover	2
J	Water-blocking aluminum material	1
K	Guide Block	1
L	Pulley adjustment tool	1

NOTE

Inspect all parts for missing prior to installation!
Contact us for any part missing.

PACKAGE CONTENT




HARDWARE CONTENT

aa




CAP
4pcs

bb



Screw
ST4*30mm
6pcs

cc




Wall anchor
Ø6X30mm
8pcs

dd



Screw
ST4X25mm
2pcs

ee



Screw
M5X10mm
2pcs

NOTE

Inspect all parts for missing prior to installation!
Contact us for any part missing.


TOOLS REQUIRED

Drill Bits



Drill Bits: 1/8" (3mm) and
1/4" (6mm) HSS


Phillips screw
driver




Electric hand drill



Level



Caulking gun



Measuring Tape




Soft Head
Hammer




Marking Pencil



Utility Knife



Sealant



MASONRY DRILL
BIT FOR TILE
Ø6mm




Safety Glasses




Gloves




Carpenter's Squarer




Masking or painter's
tape




Hack Saw



Metal File



Glass suction
Handle



SAFETY INFORMATION


CAUTION

Please carefully read the following important safety information before handling or installing this shower door. There is a risk of serious injury while handling this product.

To minimize these risks, please note:

- Always wear safety glasses and gloves while handling.
- Always follow the installation instructions.
- Inspect glass for damage before installation.
- Extreme caution should be taken while handling the glass during installation as the tempered glass may shatter if in contact with a hard surface.
- Do not cut or modify the tempered glass as it will shatter if cut.
- Carefully remove product from packaging and keep packaging until installation is complete.
- Inspect all parts for damage or missing; if there is damage or part missing to the unit prior to installation, please contact customer service at the number provided in this guide.
- Cover the drain with tape to prevent the loss of small parts.
- The shower base and finished walls should be installed before beginning the shower door installation.
- During the installation, protect the shower floor with a drop cloth to avoid damage.
- This product should be installed by two people who are familiar with construction requirements. Professional installation is recommended!
- Keep this installation manual for future reference.

NOTE: Two people should perform this installation.



1

Measure the finished opening width.


NOTE

1. Measure the finished opening width at the bottom and at the model height.

Use these dimensions as "W1"(top) and "W2"(bottom) in step#2.

2. Also check the threshold for level and the walls for plumb.

5/16"(8mm) Maximum out of plumb adjustment from top to bottom



_____ Finished opening top(W1)

_____ Finished opening bottom(W2)

2


Use a miter saw or hacksaw to cut the Upper Guide Rail(B) and Upper guide rail cover (A)

NOTE

Measure the shower room and confirm the length of the Upper Guide Rail(B) and Upper guide rail cover (A)




Note: Both sides of the upper guide rail can be cut, but be careful not to cut off the screw holes



Note: One end can only be cut at most 2"



Note: Both sides of the Upper guide rail cover (A) rail can be cut, But there should be space left for the screw holes




3

Determine your step in from the edge of the tray and plumb your Wall Jamb(D).

NOTE

1. Determine your starting point from the edge of tray(1 1/4"(32mm) is recommended) and mark the position as Fig.a.
2. Plumb your Wall Jambs(D) on each side and then mark screw hole's position as Fig.b.





4

Installation Wall Jamb(D).

NOTE

1. Drill holes with 6mm(1/4")drill bit as Fig.a.
2. Insert Wall Anchors(cc)as Fig.b.
3. Attach the Wall Jamb(D) to the wall with Screws (bb) as Fig.c.



NOTE

- If a Stud is present behind the wall:
drill $\varphi 1/8"$ (3mm) pilot holes into the stud and
use the ST4.0x30mm Screws
- OR
- If NO Stud is present behind the wall:
drill $\varphi 1/4"$ (6mm) holes and insert the Wall Anchors(bb)
and use the ST4.0x30mm Screws



5

Install Upper Guide Rail(B)

NOTE

Insert the Upper Guide Rail into the Wall Jamb (D) as shown in Fig.a

Fig.a



6

Positioning the Water-blocking aluminum materia(j) and Guide Block(k)

NOTE

- 1.Put it on the tray and adjust it, if the size is not suitable, as Fig.a. If the size is suitable ,skip to the step as Fig.b.
- 2.Position the Water-blocking Aluminum Material(J)1"(25mm)from the edge of the WII Jamb(D)and mark its position as shown in Fig.b.
- 3.Insert the Water-blocking Aluminum Material(J)into the Guide Block (K)as shown in Fig.c.
4. Make sure that the Water-blocking aluminum materia(J) is parallel and mark the position of the Guide Block(K) with a pencil and Water-blocking aluminum materia(J) as Fig.d.

Fig.a




Fig.b




Fig.c





Fig.d



7

Drill screw holes for the Guide Block (K) and insert the Wall Anchors (cc) .

NOTE

1. Drill holes with $\varphi 6\text{mm}(1/4")$ drill bit as Fig.a.
2. Insert Wall Anchors(cc)as Fig.b.

Fig.a






Fig.b



8

Install the Water-blocking aluminum material(J) and Guide Block(K)

NOTE

1. Tear off the 3M adhesive film at the bottom of the water-blocking aluminum material as Fig.a .
2. place the Water-blocking aluminum material(J) in the marked position as Fig.b .
3. Secure the Guide Block(K) with Screws (dd) as Fig.c.

Fig.a




Fig.b






Fig.c







9

Install Roller(C) and Install the Anti-Water Strip(E/H)

NOTE





1. Attach the two Rollers (C) to the Door Panel (F) as shown in Fig.a.
2. Install the Anti-Water Strip (E) onto the Door Panel (F) as shown in Fig.b.
3. Install the Anti-Water Strip (H) to the Door Panel (F) as Fig.c



10 Install the Door Panel(F)

NOTE



1. Hang the Rollers(C) on the Upper Guide Rail(B) as Fig.a and as Fig.b.



11 Adjustment

NOTE

1. Adjust this screw to make the GlassDoor(E) level as Fig.a and as Fig.b.



12

Install the guide rail cover(A), install the rear cover of the Roller(C), and install the handle(G)

NOTE

1. Fit the upper guide rail cover well (A) with the upper guide rail(B) and fix it with screws(ee) as Fig.a .
2. Assemble the rear cover of the pulley properly as Fig.b .
3. Install Handle(G) as Fig.c .

Fig.a





Fig.b





Fig.c



13 Install the End block(I), install the Wall Jamb Cap(aa)

NOTE

- 1.Apply glass glue inside the aluminum end cover as Fig.a
- 2.Install the aluminum end cover (I) onto the Water-blocking Aluminum Material (J) as shown in Fig.b.
- 3.Install caps on the holes in the wall materials as Fig.c

Fig.a




Fig.b






Fig.c



14 SEALING

NOTE

The surfaces need to be clean and free of debris before applying silicone.

NOTE

Make sure that the Shower door closes tightly and opens smoothly.
Apply a high-quality silicone sealant along the Wall Jamb and Aluminum



Allow 24 hours for the silicone to cure before using the shower.

