


Honeywell

Outdoor Oscillating Wall Fan


User Manual

Read and save these instructions before use




Model #53030

PACKAGE CONTENTS




Fan Control

Fan Assembly



Cord Clip (x6)

HARDWARE CONTENTS



Bracket Screw (x 2)
+ 2 extra

Note: Some extra hardware may be included. The quantity listed above is the number required for installation.

THANK YOU

Honeywell Ceiling Fans feature a collection of fans in various sizes and specifications to ensure your choice of indoor or outdoor fan delivers optimum performance for your room's size. You can trust the quality of Honeywell Ceiling Fans to deliver maximum airflow and stylish lighting options. Honeywell Ceiling Fans use high-quality materials that are long lasting and durable to deliver a great look and last for years to come.

SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, operate or install the product.

- Before you begin installing the fan, disconnect the power by removing fuses or turning off the circuit breakers.
- **RATED FOR WET LOCATIONS.** This fan is intended for indoor, damp, or outdoor use.
- The weight of the fan is 13.86 lb.

CAUTION:

- Do not use fan if any part is damaged or missing.
- Connect to properly grounded outlets only.
- Do not insert fingers or any other objects through the grill guard when fan is in operation.
- Disconnect the fan when moving from one location to another.
- Disconnect the fan when removing guards for cleaning.
- Do not use fan near windows. Rain and water may create an electrical hazard.
- Do not alter the fan's assembly.

SAFETY INFORMATION


⚠️ WARNING:

- To reduce the risk of fire or electrical shock, do not use this fan with any solid state speed control device.
- This product employs overload protection (fuse). A blown fuse indicates an overload or short-circuit situation. If the fuse blows, unplug the product from the outlet. Replace the fuse as per the user servicing instructions (follow product marking for proper fuse rating) and check the product. If the replacement fuse blows, a short-circuit may be present and the product should be discarded or returned to an authorized service facility for examination and/or repair.
- Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
- To Reduce The Risk Of Fire, Electric Shock Or Injury To Persons, Do Not Use Replacement Parts That Have Not Been Recommended By The Manufacturer (e.g. Parts Made At Home Using A 3D Printer).

CARE AND MAINTENANCE

Important: Shut off the main power supply before you begin any maintenance task. Do NOT use water or a damp cloth to clean the fan.

Clean the motor housing and blades with a soft brush or lint-free cloth to avoid scratching the finish.



The plug is a safety feature, it contains a safety device (fuse), if your replaceable fuse (5 Amp, 125 Volt) blows, please follow below instructions to replace the fuse:

- a) Unplug your fan, grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.
- b) Slide open the fuse cover at the side of the plug by using your thumb or a flat screwdriver.
- c) Remove the fuse carefully.
- d) Put in a new 5 Amp 125 Volt fuse and make sure it is secured in place.
- e) Slide back the fuse cover completely.
- f) Risk of fire. Do not replace attached plug. Contains a safety device (fuse) that should not be removed. Discard product if the attached plug is damaged.

PREPARATION

Before beginning the assembly of this product, ensure all parts are present. Compare all parts with the package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated assembly time: 1 hour

Tools required (not included): Phillips Screwdriver, level, drill, 1/8" drill bit, stud finder and pencil.

ASSEMBLY INSTRUCTIONS

1. Remove the mounting screw from the underside of the fan base. Then remove the mounting bracket (Figure 1.1).
2. Use a stud finder (sold separately) to locate the stud to which the fan will be mounted. Determine the desired height of the mounting bracket. Hold the mounting bracket against the wall and use a level (sold separately) to ensure the mounting bracket is level with the horizon. Then, use a pencil and mark the center of the two holes in the center of the mounting bracket. Note: When determining the location of the fan, ensure proximity to 120 V grounded outlet. The wall fan's power cord is 9 feet in length (Figure 1.2).
3. Use a Phillips screwdriver to install the two bracket screws through the mounting bracket, drywall (if applicable), and into the stud. Note: Drilling pilot holes can make screw installation easier. If desired, use a drill with an 1/8" diameter drill bit (or smaller) to drill the pilot holes (Figure 1.3).
4. Hang the slot in the base of the fan on the hook preassembled to the mounting bracket (Figure 1.4).
5. Replace the previously removed mounting screw into the fan base to secure the base to the mounting bracket (Figure 1.5).
6. Plug the fan's power cord into a 120 V grounded outlet (Figure 1.6).






Figure 1.1

Figure 1.2

Figure 1.3






Figure 1.4

Figure 1.5

Figure 1.6

ASSEMBLY INSTRUCTIONS

7. Use cord clips to secure the fan's power cord to ceiling in a path toward the power outlet. Peel the backing off of the double-sided tape preassembled to back side of each cord clip (Figure 1.7).
8. Optional) Cord clips have a round hole to accommodate a wood screw (sold separately) as an option to the taping method (Figure 1.8).
9. Secure each cord clip to the ceiling. Then insert the cord into each clip and press the clip closed to secure the cord. Note: Leave adequate slack near the fan to allow fan to swivel and/or tilt (Figure 1.9).




Figure 1.7




Figure 1.8




Figure 1.9

OPERATING INSTRUCTIONS

1. Use the two knobs on the front of fan base to control the fan (Figure 2.1).

Oscillation Control - Turns oscillation off and on.

Speed Control - Turn knob to 1 for Low Speed, 2 for Medium Speed, or 3 for High Speed.

2. Use the tilt knob on side of fan to adjust airflow up or down. Loosen tilt knob by turning counterclockwise, adjust fan, and retighten tilt knob (Figure 2.2).




Figure 2.1




Figure 2.2

TROUBLESHOOTING

If you experience any faults, please check the Troubleshooting section below. If a problem cannot be remedied or you are experiencing difficulty in installation, please contact Customer Service: 1-877-361-3883, Monday - Friday, 8am - 5pm, Central.

WARNING: Shut off the power supply before you begin any maintenance task.

PROBLEM	CORRECTIVE ACTION
The fan does not move.	<ol style="list-style-type: none">1. Ensure the main power cord is plugged into a 120 V receptacle.2. Replace fuse in plug (see MAINTENANCE, page 4).

WARRANTY

The manufacturer warrants all of its utility fans against defects in materials and workmanship for three (3) years from the date of purchase. If within this period the product is found to be defective, take a copy of the bill of sale as a proof of purchase and the product in its original carton to the place of purchase. The manufacturer will, at its option, repair, replace or refund the purchase price to the consumer. All costs of installation and removal of the fixture is the responsibility of the consumer. This warranty does not cover utility fans becoming defective due to misuse, accidental damage or improper handling and/or installation and specifically excludes liability for direct, incidental or consequential damages. As some states do not allow exclusions of limitations on an implied warranty, the above exclusion and limitation may not apply. This warranty gives you specific rights and you may also have other rights which may vary from state to state.

The Honeywell Trademark is used under license from Honeywell International Inc.

Honeywell International Inc. makes no representations or warranties with respect to this product.

This product is manufactured for
Hong Kong China Electric Appliance, LTD.
3350 Players Club Parkway, Suite 225
Memphis, TN 38125
1 (877) 361-3883

10203 • 102924