

WARNING!!

Children have died from furniture tipover. Tip restraints have been included with this product; you must install the tip restraints according to these instructions in order to minimize the risk of furniture tipping.

NEVER allow children to climb or hang on furniture, including drawers or cabinet doors.

In addition to installing the restraints, to help prevent tip-over

1. NEVER put a TV or other heavy objects on top of this product".
2. Do not stand on the product




Assembly Instructions

Caution : You must read this before you proceed




Care & Maintenance

- Ø 
 - Not for commercial use. For residential use only.
- ✓ 
 - Furniture may scratch floors. We recommend using furniture pads to protect your floors.
- Ø 
 - Do not put hot items directly on furniture surface.
- Ø 
 - Do not clean furniture with harsh cleansers or polish.
- Ø 
 - Do not place furniture under direct sunlight.
- Ø 
 - Do not place furniture near heating or cooling vents.
- Ø 
 - Do not write on furniture without a padded barrier to protect the surface.
- Ø 
 - Do not place furniture outside . For indoor use only.
- Ø 
 - Stains may be removed with mild soap solution and damp cloth.
- Ø 
 - Children should not climb or jump on the furniture.
- ✓ 
 - Dust and pick-up spills using a clean, non-colored, lint-free cloth.


Please look in small carton box for Hardware packs.




▲
* Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe !!!
* Please assemble on a clean soft surface to avoid damage.



Tools Required



(Not included)



(Not included)

IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

Before Installation


Important – Please read these instructions fully before starting assembly

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.


Cam Lock Assembly Instructions

Diagram A




Insert Cam Ball into hole as shown in diagram A.

Diagram B




Make sure not to insert the Cam Bolt:
Too deep as shown in figure B as this will cause
the cam Lock to be misaligned and unable to
interlock properly.

Diagram C




Also avoid inserting the Cam Bolt too close to the
surface of the hole as shown in figure C, as this
will cause the Cam Lock to be too loose, and not
interlock properly.


Connect the panels together.











Insert the Cam Lock so the side opening fits over
the head of the Cam Bolt.







To tighten the Cam Lock, turn it clockwise on half
a turn with a flat screwdriver.
*Do not use an automatic screwdriver as it may
bend or break if too much power is imposed.





PACKAGE CONTENTS

 <p>A</p> <p>Top Panel - 1 pc</p>	 <p>B</p> <p>Left Side Board - 1 pc</p>
 <p>C</p> <p>Right Side Board - 1 pc</p>	 <p>D</p> <p>Left Vertical Panel - 1 pc</p>
 <p>E</p> <p>Right Vertical Panel - 1 pc</p>	 <p>F</p> <p>Shelf - 1 pc</p>
 <p>G</p> <p>Bottom Panel - 1 pc</p>	 <p>H</p> <p>Back Panel - 2 pcs</p>
 <p>I</p> <p>Leg Panel - 2 pcs</p>	 <p>J</p> <p>Support Bar - 2 pcs</p>
 <p>K</p> <p>Left Door - 1pc</p>	 <p>L</p> <p>Right Door - 1 pc</p>


PACKAGE CONTENTS

M		N	
Drawer Front Panel - 6 pcs			Drawer Left Panel - 6 pcs
O		P	
Drawer Right Panel - 6 pcs			Drawer Back Panel - 6 pcs
Q			
Drawer Bottom Panel - 6 pcs			

HARDWARE CONTENTS

1		Ø6*35mm	Three in one bolt - 45pcs	2		Ø15*9mm	Three in one lock - 45pcs	3		Ø6*30mm	Wood dowel - 21pcs	4		5/32"*20mm	Handle bolt - 10pcs
5		Handle - 6pcs		6		Handle - 2pcs		7		Ø3*15mm	Round head screw - 27pcs	8		Ø6*40mm	Bolt - 5pcs
9		Ø3*12mm	Flat head screw - 9pcs	10		Ø4*25mm	Flat head screw - 25pcs	11		Ø4*50mm	Round head screw - 15pcs	12			Allen Wrench - 1pc
13		Anti fall hardware- 2pcs		14		Ø4*20mm	Flat head screw - 2pcs	15		Ø4*35mm	Flat head screw - 2pcs	16		Ø8*40mm	Plastic wall bolt - 2pcs


STEP 1



3		4pcs
---	--	------

Insert Wood dowels (3) into drilled holes on the Shelf (F) with Hammer (Not provided).


STEP 2



1		4pcs
3		8pcs

Insert Three in one bolt (1) and Wood dowels (3) into drilled holes on the Left Vertical Panel (D), Right Vertical Panel (E) with Screwdriver and Hammer (Not provided).


STEP 3



3 8mm wood dowels

Insert Wood dowels (3) into drilled holes on the Left Side Board (B), Right Side Board (C) with Hammer (Not provided).


STEP 4



2 4mm three in one locks

Attach Shelf (F) to Left Vertical Panel (D) and Right Vertical Panel (E) using Three in one lock (2) with Screwdriver (Not provided).


STEP 5



1 16pcs

Insert Three in one bolt (①) into drilled holes on the Top Panel (A), Bottom Panel (G) with Screwdriver (Not provided).


STEP 6



2 4pcs

Attach Top Panel (A) to Left Vertical Panel (D) and Right Vertical Panel (E) using Three in one lock (②) with Screwdriver (Not provided).


STEP 7



2 4pcs

Attach Top Panel (A) to Left Side Board (B) and Right Side Board (C) using Three in one lock (2) with Screwdriver (Not provided).


STEP 8



2 8pcs


Attach Top Panel (A) to Left Side Board (B), Left Vertical Panel (D), Right Side Board (C) and Right Vertical Panel (E) using Three in one lock (2) with Screwdriver (Not provided).

STEP 9




Attach Support Bar (J) to Leg Panel (I) using Bolt (8) with Allen Wrench (12).

STEP 10



Attach Leg Panel (I) and Support Bar (J) to Bottom Panel (G) using Screw (11) with Screwdriver (Not provided).


STEP 11



7 26pcs

Attach Back Panel (H) to the Cabinet back using Screw (7) with Screwdriver (Not provided).


STEP 12



9 8pcs


Attach Leg Door (K) to Left Vertical Panel (D) and Right Door (E) to Right Vertical Panel (B) using Screw (5) with Screwdriver (Not provided).

STEP 13




Attach Handle (⑥) to the Door using Bolt (④) with Screwdriver (Not provided).

STEP 14




Insert Three in one bolt (①) into drilled holes on the Drawer Front Panel (M) with Screwdriver (Not provided).

STEP 15




Attach Drawer Left Panel (N) and Drawer Right Panel (O) to the Drawer Back Panel (P) using Screw (10) with Screwdriver (Not provided).

STEP 16



Attach Drawer Back Panel (Q) to the Drawer Left Panel (N), Drawer Right Panel (O) and Drawer Back Panel (P).


STEP 17



2		24pcs
---	--	-------

Attach Drawer Front Panel (M) to the Drawer Left Panel (N) and Drawer Right Panel (O) using Three in one lock (②) with Screwdriver (Not provided).


STEP 18



4		6pcs
5		6pcs


Attach Handle (⑤) to the Drawer Front Panel using Bolt (④) with Screwdriver (Not provided).

STEP 19



Attach Drawer to the Cabinet.

STEP 20



13		2pcs
14		2pcs
15		2pcs
16		2pcs

20.1) Connect the Anti fall hardware (13) to Cabinet with help of Round head screw (14) and Screwdriver (Not provided) same as other side.

20.2) Move the Cabinet back to the wall. Mark two points same width of Cabinet on the wall.

20.3) Drill two holes on wall at 5 cm below from the height of Cabinet as Anti fall hardware on the Cabinet with Power Drill (Not provided).

Insert Plastic wall bolts (16) into drilled holes on the wall with Hammer (Not provided).

20.4) Attach Anti fall hardware (13) to Plastic wall bolts (16) using Round head screw (15), and Screwdriver (Not provided) same as other side.

Your Cabinet is ready for use.

This Cabinet can only be used on a flat, level surface.