



# User Manual

## SOLAR LANDSCAPE LIGHT



### Working process instruction



**Switch Button**  
 1. ON/OFF: Long press for 15S.  
 (After the initial activation, the lamp will turn on/off automatically when dark/down.)  
 2. Change lighting mode: Short press.

**Lighting Mode**  
 M1: 25% tilt down  
 M2: 50% tilt down  
 M3: 75% tilt down  
 M4: 100% tilt down

**Caution**  
 This light bulb is related below 3.3V, do not overload. Connect with any voltage higher than 3.3V is prohibited.

### Special Note:


1. Do not install the lamp in places facing away from the sun, under the shadow, or between two buildings whose height is above the lamp. Otherwise, it will result in insufficient absorption from sunlight and insufficient working brightness and time.
2. Do not use the lamp in the environment temperature above 45°C or below 0°C, otherwise, it will cause the battery rapid attenuation and affect the battery lifetime, even damage.
3. Do not use non-standard accessories to install the lamp, otherwise, any caused accident will be borne by the installer.
4. Please charge the lamp not less than every 3 months to ensure the lithium battery activity.
5. If the product has been stored in the warehouse for more than one year, please do fully charge and discharge inspection and make sure the battery is in good condition. Otherwise, it is forbidden to use.

### Warning:

1. Keep the device away from fire and oil to avoid any fire or explosion.
2. No one except professional technicians should attempt to disassemble the light to avoid damaging the light.
3. It is strictly forbidden to disassemble the battery for personal use.
4. If the lamp doesn't get charged for 3 days, the battery maybe out of power, please charge it under bright sunlight.
5. To ensure the lamp works in an ideal state for a long lifetime, please clean the solar panel regularly according to the local dust condition, it's suggested one time at least every 6 months.
6. Long time (over one year) static storage of the product will cause the inside battery damage or even leakage. When the battery leak, it will cause the battery ignite if suddenly charged by sun.

## SOLAR LANDSCAPE LIGHT

### Main Parts



- ① Solar Panel
- ② Switch Button
- ③ Lamp Body
- ④ LED
- ⑤ Base
- ⑥ Bracket
- ⑦ Pole

Battery: Li-ion Battery  
 Solar panel: Monocrystalline silicon  
 Materials: ABS

### How to install the device?

1. Nail the expansion screws into the wall. Fix the holder by screws onto the wall.
2. Fasten the bracket by screw cap.
3. Hang the lamp body on the bracket.
4. Fix the hook and main body by PM4\*8 screws.

### How to install the device?

1. Fix the pole with base by screws.
2. Nail the expansion screws and fix the base by screws.
3. Connect the pole and lamp body by screws.
4. The installation is complete.

### How to install the device?

1. Connect the poles by screws.
2. Fix the pole with base by screws.
3. Nail the expansion screws into ground and fix the base by screws.
4. Connect the pole and lamp body by screws.