

Limited Warranty Information

Thank you for choosing an Alpine product! We aim to please with our wide range of products including Fountains, Birdbaths, Statuary, Pond Supplies & More. All of our products are constructed from the highest quality materials. In the event that we have not achieved our usual standard of excellence, we will repair or replace, at our discretion, within the warranty period. A valid proof of purchase, with the purchase date clearly indicated, must be provided. Photos of defective merchandise will also be required to help distinguish the actual cause of the defect. Please read below for a detailed description of warranty coverage.

- **Water Damage**

Alpine products are not manufactured to withstand extreme temperatures. Improper storage that allows water to freeze within a product may cause damage and is considered negligence and will, therefore not be covered under this warranty. The use of "hard water" and/or caustic cleaners can affect the paint or other finishes. Failure to keep the unit clean, and use of such additives/cleaners, will also void the warranty. Please note: for fountains, it is normal for some splashing to occur and protecting the immediate surfaces is not the responsibility of Alpine Corporation

- **Paint & Color (Retention and/or Loss)**

The use of water will cause natural erosion to the color. This area can be touched up using standard paint. The paint is designed protect the entire finish against breakdown of color. As with any product, all finishes with time will gradually fade and discolor. The warranty will only cover against severe or complete fading within the first year from date of purchase with the above exclusion.

- **Procedure/Service**

Should a warranty/claim be needed, you should contact the retailer from whom you purchased the product. If that not an option, you can contact Alpine Corporation at www.alpine4u.com. When contacting Alpine Corporation, you must be prepared to show proof of purchase, provide photographs and any other information needed to validate your claim. This may be necessary to distinguish between a partial or complete replacement of a defective product. The warranty does not cover any items with multiple parts; the warranty will ONLY cover the individual component of the unit/item that may be defective. Replacement parts can be made available to a consumer through the original selling party, or an approved parts retailer. If this is not an option, contact our customer service department.

- **Not Covered Under Warranty**

The limited warranty will NOT cover cases of damages due to

1. Damages caused in Transit
2. Inadequate care and/or neglect
3. Environmental and/or natural elements
4. Immersion in water, unless specified
5. Improper Installation/Storage and/or Maintenance

This warranty is void if the product has been damaged by accident, misuse, negligence, improper installation and/or modifications have occurred. This includes any and/or all defects arising out of freezing water damage, hard water damage, failure to keep the unit clean and free of harmful additives such as bleach, chlorine, etc.... which affects the paint and/or parts. This warranty also does not cover any additional charges or installation, removal, disposal and/or shipping costs or consequential damage associated with any warranty claim



LED9003T 3 Warm White LED Light with Stake, Transformer and Photocell



Assembling & Using Your Product

Unpack all components carefully. Please check to ensure all parts have been removed from the packaging.

Components:

LED9003T Light
Transformer
Stake
Photocell

Operating Instructions:

- This light must be used with a transformer. Please use a transformer with the correct wattage and never exceed the maximum wattage indicated on the transformer
- Before plugging in the unit, be sure the input voltage indicated on your transformer is the same as your local power supply. If not, please do not operate the light until you obtain the appropriate transformer from your local dealer.
- To reduce the risk of electrical shock, inspect all cords for damage before installation.
- Plug the connector of the light into the socket on the transformer and screw the coupling until tight.
- Plug the transformer into the outlet.

Changing the Bulb or Lenses to your Illumination Light:

- Make sure to unplug the transformer and remove it from the water (if submerged)
- After allowing a sufficient amount of time for the light to cool, let it dry and remove the lens retainer from the light by pushing on it and turning counter-clockwise quickly.
- Remove the lens carefully and make sure the "O" ring stays in place
- Gently pull out the socket and remove the bulb and replace with the new set rating power bulb by aligning the pins of the bulb into the socket.
- Gently push the new bulb down, DO NOT force it. Turn power bulb around if it does not fit easily.
- To maintain a water tight seal, make sure the lens is flush with the front lip of the rubber seal.
- Make sure the lens is on the rubber seal then take the cover and place it correctly onto the slots of the light, turning tightly clockwise.
- Make sure the cover is tightly locked

Trouble Shooting & Caution

If you have any questions and/or problems, please contact the retail store you purchased this light.

If the light fails to illuminate, please check the following:

- Check that the light set is getting power by testing another applicant in the power outlet that the lights use
- Check to ensure that your light bulb has not burned out from usage
- If water gets into any of your lights, lift it out of the water, remove the lens and empty the water until dry

Caution & Warning

- Always handle the light from the base. The light housing can and will become HOT!
- Operating the lights with missing or damaged covers can result in risk of fire or electrical shock
- Use ONLY recommended Alpine rating power bulbs
- Do not exceed the voltage & wattage indicated on the transformer
- This light assembly has not been tested or designed for use in swimming pools and hot tubs

